



Instruction Manual

Please save this manual for future reference.

| | |
|----------------------|--|
| Product Name: | Children Fishing Garden Statue with Solar String Light |
| SKU #: | WHST258 |

Thank you for purchasing this Winsome House product. This product has been manufactured with the highest standards of safety and quality.

Parts included:

Children Statue, Hoop

Insert the hoop stem into the hole of the handle.



To turn the solar light on, push button on the back of the solar panel to the “On” position, and allow solar panel to charge for a full 8 hours in direct sunlight. The solar string light will work for 6-8 hours after a full charge.

To replace the battery:

Unscrew the back panel of the solar panel, and replace the battery with the exact same rechargeable battery type. Screw the back panel on the solar panel, and allow battery to charge for full 8 hours in direct sunlight.

Battery type: Ni-MH AAA 200mAh 1.2V

| | |
|----------------------|--|
| Product Name: | Children Fishing Garden Statue with Solar String Light |
| SKU #: | WHST258 |

Tip:

If the solar string light ("fishing line"), does not reach the mouth of the fish, try gently bowing the fishing rod.



Trouble Shooting Tips:

If your solar light does not turn on at night, it may be caused by the following:

1. Check to see if the switch is in the "OFF" position.
Resolution: Move the switch to the "ON" position and allow the solar light to be charged for at least 8 hours in direct sunlight.
2. Battery may not be fully charged.
Resolution: Make sure the solar light is placed in an area where the solar panel receives the maximum amount of full direct sunlight every day.
3. The solar light may be located too close to other light sources (such as porch light or street lantern).
Resolution: Relocate away from external light source.
4. The rechargeable battery may need to be replaced.
Resolution: Replace with batteries of identical specification.



WARNING:

Do not dispose of batteries in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling batteries or disposing of them in accordance with Local, State, and Federal regulations.