
Assembly Instructions



Console Table

Model No. HOGA-F1783/F1800/F1866


Contact Us We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

- 1. Carefully read these instructions and keep them for future reference.
- 2. Check the parts list and confirm everything's there before starting assembly.
- 3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
- 4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.




We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.




Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.










Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.


Parts List




Hardware List

Α	В	С	D
M6x12mm	M6x40mm	M6x45mm	φ7x40mm
8 pcs+1 pc	14 pcs+1 pc	6 pcs+1 pc	4 pcs+1 pc

E	F	G	Н
φ7x70mm	φ8x30mm		
Ψέλειστι			
8 pcs+1 pc	2 pcs+1 pc	2 pcs	4 pcs









Α	В	
9		
M6x12mm	M6x40mm	
8 pcs	8 pcs	











Е	F	
(Communication)		
φ7x70mm	φ8x30mm	
8 pcs	2 pcs	














Thank you for your support!

