




### Before You Start


- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

## Assembly

**1**


Standing to one side of the tent, grab the opposite side and pull it towards you, and fold the tent flat.

2




Fold the tent in half towards you, so that the top of the tent touches the bottom. Grab the top and bottom of the tent with one hand, making sure that you get both pieces at the bottom. You should now be holding the tent between two loops.

3




Pick up the tent and rotate it by 90 degrees so that it is now sitting with one loop on top of the other.

4




Grab the top loop (A) with one hand, while holding the side of the tent with your other hand (B).

5



Fold the loop (A) down and place it under itself, as your other hand (B) rolls over the top.



Release the tent with your top hand (B) and allow the tent to slide over and collapse on the top of itself.



### Return / Damage Claim Instructions

- ⚠ **DO NOT discard the box / original packaging.**  
In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- ⚠ **Take a photo of the box markings.**  
A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- ⚠ **Take a photo of the damaged part (if applicable).**  
A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- ⚠ **Send us an email with the images requested.**  
Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.