






PARTS LIST

HANDHELD BLOWER

MODEL: PHB2415









Version: B - Issue Date: 2023/03/15




SPARE PARTS / ELECTRICAL

FLAME OUT ASSEMBLY

Part Number: 68841501


No.	Description	Qty
61	Switch Clear Cover	1
62	Switch	1
63	Switch Line	1



HIGH PRESSURE PACKAGE

Part Number: 20051399


	No.	Description	Qty
ſ	27	Ignition Coil Assembly	1



SPARE PARTS / CHASSIS AND ENCLOSURE

FUEL TANK ASSEMBLY

Part Number, 2007 1559	
Description	Qty
Fuel Tank Cap	1
Rubber Valve	1
Rubber Valve Mount	1
Gasket	1
Chain Mount	1
Chain	1
Fuel Tank	1
Fuel Hose Mount	1
Return Hose	1
Fuel Hose	1
Clip	1
Fuel Filter Assembly	1
Fuel Tank Mount	1
Washer	1
Self-Tapping Screw ST4.8x19	1
	Description Fuel Tank Cap Rubber Valve Rubber Valve Mount Gasket Chain Mount Chain Fuel Tank Fuel Hose Mount Return Hose Fuel Hose Clip Fuel Filter Assembly Fuel Tank Mount Washer






SPARE PARTS / CHASSIS AND ENCLOSURE

IMPELLER COVER ASSEMBLY

Part Number: 68841502


No.	Description	Qty
87	Cover	1
86	Cover Spring	1



SPARE PARTS / STARTING MECHANISM


STARTER ASSEMBLY

Part Number: 20085774		
No.	Description	Qty
4	Starter Cover	1
5	Starter Handle	1
6	Washer Ф5.5хФ16х15	1
7	Spiral Spring	1
8	Starter Pull Cord	1
9	Starter Pulley	1
10	East Spring	1
11	Starter Pawl	1
12	Washer Ф5хФ11х12	1
13	Self-Tapping Screw ST5x16	1



STARTER GRIP AND ROPE ASSEMBLY

No.	Description	Qtv
	Starter Handle	1
8	Starter Pull Cord	1






SPARE PARTS / STARTING MECHANISM

STARTER COVER

Part Number: 20068614


No.	Description	Qty
4	Starter Cover	1



SPARK PLUG

Part Number: 20079314

No.	Description	Qty
42	Spark Plug	1




SPARE PARTS / TUBING

TUBE SERPENTINE ASSEMBLY


Part Number: 20071533

No.	Description	Qty
105	Tube Surpentine	1
106	Safety Fence	1



TUBE FRONT ROUND

No.	Description	Qty
107	Tube Front Round	1






SPARE PARTS / CARBURETOR

CARBURETOR ASSEMBLY

Part Number: 68841504

No.	Description	Qty
53	Carburetor	1
54	Carburetor Gasket	1




SPARE PARTS / FILTER AND ACCESSORIES

AIR FILTER


Part Number: 20051401

No.	Description	Qty
56	Air Filter	1




AIR FILTER COVER

No.	Description	Qty
57	Air Filter Cover	1



ASSEMBLY PARTS LIST





ASSEMBLY PARTS LIST

No.	Description	Qty
1	Self-Tapping Screw ST4.2x12	3
2	Top Cover	1
3	Cap Screw M5x16	3
4	Starter Cover	1
5	Starter Handle	1
6	Washer Ф5.5хФ16х15	1
7	Spiral Spring	1
8	Starter Pull Cord	1
9	Starter Pulley	1
10	East Spring	1
11	Starter Pawl	1
12	Washer Φ5xΦ11x12	1
13	Self-Tapping Screw ST5x16	1
14	Starter Pulley Assembly	1
15	Oil Seal Φ12xΦ22x7	1
16	Crankcase LH	1
17	Pin	2
18	Bail Bearing 6001 / P5	1
19	Gasket	1
20	Bail Bearing 6001 / P5	1
21	Crank Shaft Connecting Rod Assy	1
22	Crankcase RH	1
23	Oil Seal Φ12xΦ22x7	1
24	Cap Screw M5x28	3
25	Woodruff Key 3x3.7x10	1
26	Holder	1
27	Ignition Coil Assembly	1
28	Switch Line	1
29	Rotor Fan	1
30	Cap Screw M5x25	2
31	Nut M8x1	1
32	Shaft	1
33	Cap Screw M6x20	2
34	Piston Pin Clip	2
35	Piston Pin	1
36	Needle Bearing	1
37	Piston	1
38	Piston	2
39	Gasket	1

No.	Description	Qty
40	Cylinder	1
41	Cap Screw M5x20	4
42	Spark Plug	1
43	Cap Screw M5x60	2
44	Muffler Cover	1
45	Muffler Assembly	1
46	Muffler Gasket	1
47	Insulator Gasket	1
48	Insulator	2
49	Cap Screw M2x22	1
50	Metal Plate	1
51	Screw M4x6	1
52	Carburetor Gasket	1
53	Carburetor	1
54	Carburetor Gasket	1
55	Cap Screw M5x50	2
56	Air Filter	1
57		1
58	Self-Tapping Screw ST4.8x16	2
59	Self-Tapping Screw ST4.8x14	3
60	Right Handle	1
61	Switch Clear Cover	1
62	Switch	1
63	Switch Line	1
64	Trigger	1
65	Trigger Line	1
66	Self-Tapping Screw ST4.8x10	1
67	Speed Lever	1
68	Waves Washer	2
69	Left Handle	1
70	Speed Knob	1
71	Front Rubber Grip	1
72	Rear Rubber Grip	1
73	Anti-Spring Mount	2
74	Self-Tapping Screw ST4.8x10	2
75	Anti-Spring	2
76	Air Duct	1
77	Down Handle	1
78	Right Fan Cover	1



ASSEMBLY PARTS LIST

No.	Description	Qty
79	Cap Screw M5x16	4
80	Fan	1
81	Washer	2
82	Nut M8x1	1
83	Pipe Lock	1
84	Spring	1
66	Self-Tapping Screw ST4.8x10	1
85	Left Fan Cover	1
86	Cover Spring	1
87	Cover	1
88	Self-Tapping Screw ST4.8x25	5
89	Self-Tapping Screw ST4.8x19	1
90	Fuel Tank Cap	1
91	Rubber Valve	1
92	Rubber Valve Mount	1

No.	Description	Qty
93	Gasket	1
94	Chain Mount	1
95	Chain	1
96	Fuel Tank	1
97	Fuel Hose Mount	1
98	Return Hose	1
99	Fuel Hose	1
100	Clip	1
101	Fuel Filter Assembly	1
102	Fuel Tank Mount	1
103	Washer	1
104	Self-Tapping Screw ST4.8x19	1
105	Tube Surpentine	1
106	Safety Fence	1
107	Tube Front Round	1