

145.00 mm

User Manual
Floor Fan

1. Clean the blade by using a soft, damp cloth then wipe with dry cloth. Please be caution around the motor housing area.
2. Do not allow the motor or other electrical components to be exposed to water.
Reassemble after cleaning by reversing above procedure.
3. Do not bend the blades.
4. The internal motor bearings are permanently lubricated at the factory and do not require any additional.

User Manual
Floor Fan

A large, black, industrial-style electric fan. It features a circular grille with a radial pattern of thin metal bars. The fan is mounted on a sturdy, black metal frame that includes a handle on the right side for carrying. The fan blades are visible through the grille. The overall design is functional and durable.

145.00 mm

User Manual

Floor Fan

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord
2. Risk of fire. Do not replace attachment plug. Discard product if the attachment plug is damaged.

User Manual
Floor Fan

1. Align Cradle Base with support brackets attached to fan body sides. Note: you may need to flex the parts to make them align properly.
2. Insert support bracket into opening of cradle base. Press spring loaded button down to allow it to insert into cradle base, see Fig.1.
(12 inch is an integrated bracket, no need to assemble)
3. Press support bracket into cradle base until spring button protrudes out open hole in cradle base, see Fig.2.
4. Repeat above process for opposite side of fan.

