

DeckTok


USER MANUAL

Smart Mushroom Path Lights

What You Get

ITEM	QUANTITY
Power Adapter	1
Control Box	1
Lamp Body	2
Ground Stake	2
Lampshade	2
Waterproof End Cap	1
User Manual	1

At a Glance



- ① Pathway Lights
- ② Control Box
 - Press once to switch modes.
 - Press twice to power on/off.
 - Long press for 5 seconds light flashing in connection network mode.
- ③ Power Adapter
- ④ Waterproof End Cap


Installing Your Device

You'll need




Lampshade

2 PCS



Path light

2 PCS



Ground Stake

2 PCS




Waterproof End Cap

1 PCS


1. Assembling the Path Light

Attach the path light to its stand by rotating the stand clockwise until firmly secured.




2. Attaching the Path Light to the Ground Stake

Screw the ground stake into the bottom of the path light stand by rotating the light body clockwise until it is fully secured.




3.Installing the Lampshade

Screw the lampshade onto the top of the path light until it is firmly secured.




4.Linking the Path Lights

Press the male and female connectors together and turn the sleeve to secure their connection.




***Note:** Link up to 4 units maximum



***Note:** Install the waterproof end cap on the last pathway light.

5.Inserting the Ground Stake

Find the desired location. Plant the path light by firmly pressing the ground stake into the soil.



***Note:** When installing the product in hard or dry soil, water the soil several hours beforehand to make the installation easier. You can also break up the ground with a stake or a fork. Don't force the stake into the ground as excess force can break or bend the stake.

Setting Up The System

1. Download the Decktok App from App Store for iPhones / Google Play for Android smartphones.



2. Connect to a WiFi supporting 2.4GHz and enable your smartphone's Bluetooth.
3. Press the on/off button on the control box for 5 seconds. When the light flashes, you can open the App.
4. On App home page, tap “Add Device” or tap “+” icon at the upper right corner and allow it to search for the light device.
5. Wait for the device icon to appear. Tap the device icon and follow the on-screen instructions to complete pairing.

Specifications

Adapter Input	AC 100-240V
Power Input	27V / 0.88A
Length	24.15ft (7.36m)
Light Color	RGBWW
Waterproof	Light: IP65 Control Box: IP65 Power Adapter: IP44
Wireless Protocol	2.4GHz Wi-Fi + Bluetooth
Working Temperature	-4°F-113°F

Notice

- The product is for outdoor use only.
- Tighten up all the waterproof connector caps before use.
- Do not submerge the product in water or other liquids.
- Do not expose it to splashing or dripping water.
- Do not install the product near heat sources or in damp locations.
- Use the product with the provided power adapter only. Using unauthorized adapters may be dangerous.
- Be careful with the sharp ground stakes of the product.
- The recommended temperature range for devices and accessories is -20°C to 40°C (-4°F to 104°F) .
- Do not allow children to install this product.
- This product is not a toy. Children and the disabled should use it under adult supervision.

Troubleshooting

1.Unable to connect to the App

- Ensure the device is powered on.
- Check if Bluetooth is enabled on your phone.
- Make sure your phone is connected to a 2.4GHz Wi-Fi network.
- If not, set the router to 2.4GHz and then reset it.

Long-press the control box button for five seconds until the light flashing in connection nextwork mode.

2. Some lights do not glow

- Unplug the adapter and plug it back in.
- If the issue persists, please contact DeckTok's official customer service.

Customer Service

Warranty: 12-month Limited Warranty

 www.decktok.com

 info@decktok.com

