













## Installed on the wall

The hanger can be installed unilaterally against the wall by fixing the vertical pole to the wooden pole of the wall frame. There must be a distance of 48 inches between the wooden poles of the wall frame. Other hardware required for this installation is not included.



## **WARNING**

This product contains small parts. If swallowed, there is a danger of suffocation. Keep these small parts away from children.

• Make sure you have read the manual before installation and fully understand how to install. If you do not understand any of the installation steps, please contact a professional installer.

• The ceiling must be able to support the weight of the bracket and the display, otherwise please strengthen the structure of the ceiling in time to strengthen the ceiling's bearing capacity.

• When installing, please wear safety clothes and use the matching tools. At least two people should complete the installation together. Failure to wear safety clothes may cause human damage, serious injury or death.

• Please check the connecting parts in time every two months to confirm whether the screws are loose.

Such products must be installed on wooden or concrete walls. Before installation, be sure to confirm the load capacity of the ceiling, and do not exceed its maximum load of 551.2lbs/250kg, otherwise it will cause product damage or personal injury

Please note that this product is only used indoors, if it is used outdoors, it may cause product damage or personal injury.