

Cleartex Megamats - Use & Care

Floor mats are highly cost-effective in protecting expensive floor coverings from loss of appearance, wear and damage. They have an embossed upper surface, and are translucent so that the appearance of the underlying floor covering remains visible.

In addition to facilitating easier movement of office chairs, particularly on carpeted floors, they can also be used on any flooring area needing protection, such as under areas used by pets, children's high chairs, and indoor pot plants.

Please note:

Megamats are suitable for use on smooth hard floors or all pile carpeted floors. Use on uneven flooring can result in damage to the mats from caster based chairs.

Use & Care:

Correct use and care of your floor mat will ensure its serviceability and durability as well as giving best protection for your floor covering.

- When room temperatures are below those recommended above normal use could be harmful: allow room temperatures to rise before using.
- As with any household or office product, handle with care at all times to maintain quality and durability.
- Floor mats are precision cut to size: do not cut or in any way alter mats as this can impair performance.
- Do not use in wet areas.
- Do not use where there are extremes of temperature.
- Do not subject mats to excessive concentrated loads.
- Do not use floor mats under office chairs which have metal castor wheels.
- Take care to avoid contact with solvent based paints, inks, varnishes, alkali cleaners, bleaches and oils: these are particularly harmful to polycarbonate.
- Clean only with a cloth or sponge soaked in mild soapy water.
- Do not use smooth floor mats on ridged, pitted or uneven concrete as they will be damaged by office chair loadings.
- Floors with rough textured floor tiles, or deep or wide grooves between tiles will damage mats under office chairs.