

PARTS AND HARDWARE


Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.

Do not fully tighten bolts until assembly is complete.


1. SOFA




A. Sofa
2X




B. Sofa Leg
2X



C. Sofa Leg
2X



D. Sofa Leg
4X



E. Cushion
2X




F. Back Cushion
2X



G. Table Top
1X



H. Table Glass
1X



I. Table Leg
1X





J. Bolt/Washer
4X



K. Bolt / Washer
24X






L. Allen Key
1X



2.TABLE

Please the table top and table leg along the arrow.



ASSEMBLY INSTRUCTIONS