



Manufactured by – Petersen Brands – 3721 N. Ventura Drive, Suite 180 – Arlington Heights, IL 60004

Thank you for purchasing the Wobble Light Jr.® Your Wobble Light Jr.® should endure normal abuse and last trouble free for years. In the rare case that you do have a problem, or can not find replacement bulbs in your area, please feel free to call our customer service at 877-707-0800 or contact us through our web site at www.wobblelight.com .

WARNING! DO NOT plug power into the Wobble Light Jr.® until it is completely assembled.

WARNING! Bulbs get very hot immediately upon illumination and can cause burns.

WARNING! Bulbs stay hot for an extended period of time after the Wobble Light Jr.® has been turned off and can cause burns.

WARNING! Use in dry locations ONLY.

WARNING! DO NOT cover the Wobble Light Jr.® with any item or lay anything on top of the light.

Assembly Instructions:

1. Screw In Bulb that has been provided. **NOTE: The model with a Fluorescent bulb has special silicone bumpers attached to the glass. DO NOT REMOVE.**
2. Place plastic dome over bulb with handle facing the switch side of the Wobble Light Jr.®
3. Secure plastic dome using screws provided.
4. Your Wobble Light Jr.® is now ready to use.

Using The Wobble Light Jr.® :

1. Product requires 16 AWG SJT or heavier, 5ft minimum in length power cord (not supplied with product.)
2. Simply plug three prong extension cord into the power inlet side of the Wobble Light Jr.®, plug the other end into a wall socket, and switch the light on. **NOTE: With the Metal Halide model, the bulb may take about 1-2 minutes to come to full brightness.**
3. Use product in upright position only.

Trouble Shooting:

I have assembled my Wobble Light Jr.®, but it does not work.

Check to see that the on off switch is in the correct position and that the extension cord is plugged into an outlet that has power.

Check to make sure that the bulb is screwed completely into the light socket.

(Metal Halide Units)

Metal halide bulbs need about 15-30 seconds to start, and then another 1-2 minutes to warm up to full brightness. You may have inadvertently switched the light off before it had enough time to start. If that did happen, you will have to wait a few minutes for the catalyst inside the bulb to reform before it will start again.

For any other problems, contact us at 877-707-0800 M-F between the hours of 8:30a and 5:00p CST



Manufactured by – Petersen Brands – 3721 N. Ventura Drive, Suite 180 – Arlington Heights, IL 60004

Limited Product Warranty

Coverage and Duration: Wobble Light® products, excluding bulbs, are warranted against defects in material and workmanship for a period of 1 Year from date of purchase (restrictions may apply outside the U.S.). This warranty does not cover:

- damages or repairs of any kind to any products, items or personal or other property resulting from use of your Wobble Light® product
- any damages caused by accidents, or abuse or misapplication of the Wobble Light® product
- failure of the Wobble Light® product to meet your requirements that differ from our specifications
- any damages caused by use of the Wobble Light® product that is contrary to the instructions or documentation accompanying your Wobble Light® product
- costs of shipment or delivery for any returns or repairs under this Limited Warranty
- damages from fire, flood, moisture, heat, acts of God or causes beyond our control
- the repair or replacement of a Wobble Light® that has been transferred to anyone other than the original purchaser

Fill out Registration Card and mail to:

Wobble Light, LLC
3721 N. Ventura Drive
Suite 180
Arlington Heights, IL 60004

Wobble Light, LLC
3721 N. Ventura Drive, Suite 180
Arlington Heights, IL 60004

Registration Card
service@wobblelight.com

Product(s) Purchased

Purchase Date

Business Name

Street Address

City

State

Zip

Email Address

Business Phone Number (Include Area Code)

Customer/Contact Person & Title

Product Purchased From