

Print in china

Instruction Manual

Outdoor Wall Sconce




PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
A	Fixture	1
В	Shade	1
С	Socket ring (preassembled to Fixture (A))	1

HARDWARE CONTENTS(shown actual size)





SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.



WARNING

- TURN OFF ELECTRICITY at main fuse box (or circuit breaker box) before beginning installation by removing fuse (or switching off circuit breaker).
- MINIMUM 90°C SUPPLY CONDUCTORS.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Times: 25 minnutes

Tools Required for Assembly (not included): Flathead screwdriver, Phillips screwdriver, Pliers, Electrical tape, Wire cutters, Safety glasses.

Helpful Tools (not included): Wire strippers, Step ladder.

Customer Service: service@24h-reply.com

4. Align the 2 screws(AA) through the holes

nuts.

Hardware Used

DD Crossbar

CFL bulb.

Long mounting screw

of the back plate, and fix them with screw

1. Attach the crossbar (DD) to the outlet box (not included) with the long mounting screws (CC).

Hardware Used


Crossbar

Long mounting screw (x 2




x 1


2. Strip 3/4 in. of insulation from wire ends. Twist stripped ends together with pliers (not included), black to black (power) and white to white (neutral). Attach copper wire to ground wire. Helpful hint: If necessary, attach copper ground wire to grounded outlet box.



5. Remove socket ring (C). Install shade (B) over socket of fixture (A), then secure with socket ring (C).



6. Install light bulb (not included). Use one standard-base bulb or one standard-base



3. Attach wire nuts (BB). Tape wire nuts (BB) and wires together.

Hardware Used



