Assembly Instruction Sheet #IS -5689W24-6 For Style 5689W24-6

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Light Source: (6) G9 40W Maximum (Not include).

Estimated Assembly Time: 15-20 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

SCIEWS.

Package Contents



A Fixture Body x1

Hardware Contents

		2000	
DESCRIPTION	QUANTIT	Y	
Decurative Caps	2рсв		
Electrical Marrets	2pcs		
Outlet Box Screw	2pcs		
Mounting Screw	2pcs		
Mounting bracket	1pcs	-	
88	CC	DD	Œ
M	Î	Î	
	Decurative Caps Electrical Marrets Outlet Box Screw Mounting Screw Mounting bracket	Decorative Caps Electrical Marrets Outlet Box Screw Mounting Screw Mounting bracket 2pcs Mounting bracket 1pcs	Decorative Caps 2pcs Electrical Marrets 2pcs Outlet Box Screw 2pcs Mounting Screw 2pcs Mounting bracket 1pcs

STEP 1 - Attach Mounting Screws, Lock Washers and Hex Nuts to Mounting bracket.




Figure 1

STEP 2 - Attach Mounting bracket to Outlet Box

A. Pass the supply wires through the Mounting bracket (EE). Attach the Mounting bracket (EE) to the Outlet Box with the head of the Green Ground Screw facing you.




Figure 2

STEP 3 - Fit Backplate to Mounting bracket Assembly

A. Fit the backplate to Mounting Screws (DD) and secure with Decorative Caps (AA). Note: The backplate should be snug against the ceiling and the Decorative Caps (AA). If not, adjust the length of the Mounting Screws (DD) by unscrewing the Hex Nut and Lock Washer and then screwing Mounting Screws (DD) in or out of the DD Mounting bracket (EE) until the correct length is achieved. Backplate Once the backplate is secure, remove the मा ਲਾ Decorative Caps (AA) and backplate and proceed to Step 4 AA Figure 3

1 of 2

