

NOTICE

*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE


Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

Part List



Model# MED9609

Product Dimensions: 47"Wx15"Dx24"H






















⚠ WARNING

This product is intended for use with a
FLAT SCREEN TV ONLY
Maximum Screen Size: 50 inches
Weight Limit: 66 lbs
Shelf Load Limit: 26 lbs
Drawer Load Limit: - lbs
Use with heavier televisions may result
in instability causing tip over resulting in
death or Serious injury.

⚠ WARNING

Death or serious injury may occur
when children climb on audio
and/or video equipment furniture.
A remote control or toys placed on
the furnishing may encourage a
child to climb on the furnishing and
as a result the furnishing may tip
over on the child.

Hardware List

HW1x6  $\varnothing 6 \times 35 \text{ mm}$	HW2x6  $\varnothing 15 \text{ mm}$	HW3x6 	HW4x12  $\varnothing 8 \times 30 \text{ mm}$	HW5x6  $M 7 \times 50 \text{ mm}$	HW6x2  $L 4$
HW7x8 	HW8x2 	HW9x2 	HW10x8  $M 3.5 \times 13 \text{ mm}$	HW11x1 	HW12x1  $M 4 \times 25 \text{ mm}$
HW13x2 	HW14x16  $M 3.5 \times 15.5 \text{ mm}$	HW15x16  $M 4.5 \times 12.5 \text{ mm}$	HW16x16 	HW17x10  $M 6 \times 12.5 \text{ mm}$	HW US90x1 
HW PM2x4 					

Part List & HW For Multi-Box Items

Piece	Description	Qty
A	Top Board	1
B	Bottom Board	1
C	Side Board Left	1
D	Side Board Right	1
E	Center Board	1
F	Adjustable Shelf	2
G	Door	1
H	Back Board	2
LT18A1	Leg	4

Piece	Description	Qty
HW1	Cambolt	6
HW2	CamLock	6
HW3	Screw Cap	6
HW4	Dowel	12
HW5	Screw M 7 x 50 mm	6
HW6	Allen Key	2
HW7	Shelf Pin	8
HW8	Sliding Top	2
HW9	Sliding Bottom	2
HW10	Screw M 3.5 x 13 mm	8
HW11	Handle	1
HW12	Screw M 4 x 25 mm	1
HW13	Stopper	2
HW14	Screw M 3.5 x 15.5 mm	16
HW15	Screw M 4.5 x 12.5 mm	16
HW16	Wedge	16
HW17	Screw M 6 x 12.5 mm	10
HW US90	Anti-Deflection Bar	1
HW PM2	Mounting Plate	4

PREPARATION


*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key


*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com




STEP1: Insert Cambolt (HW1) into Top Board (A). Insert Dowel (HW4) into Side Board Left (C), Side Board Right (D) and Center Board (E).



STEP2: Attach Side Board Left (C), Side Board Right (D) and Center Board (E) into Top Board (A). Insert Camlock (HW2) then tighten using screwdriver. Put Screw Cap (HW3) over the camlock.




Step3: Insert Back Boards (H) as figure. Put Bottom Board (B) and secure with Screw M7x50 mm (HW5), tighten screws using Allen Key (HW6).




STEP4: Install Mounting Plate (PM2) and secure with screw M 4.5 x 12.5 mm (HW15) on Bottom Board.

PREPARATION


- *Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 60 minutes.
- *Tools Required for Assembly (included): Allen Key
- *If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com




STEP5: Place Anti Deflection Metal Bar (HW US90) , secure with screw M6x12.5 mm (HW17) tighten using screwdriver.



STEP7: Insert Shelf Pin (HW7) in between Side boards and Center board on the desired level. Then place the Adjustable Shelf (F) onto the Shelf Pin. Place your furniture on level floor. The legs come with adjustable leveler, adjust it as needed until your furniture stands steadily on the floor.



STEP6: Insert Leg (LT18A1) into Mounting Plate, tighten by rotating . the leg clockwise.



STEP8: Insert Sliding Top (HW8) and Sliding Bottom (HW9) using Screw M3.5x13mm (HW10) into Door (G). Tighten with a screwdriver. Install Stopper (HW13).

PREPARATION


*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key


*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com




STEP9: Insert Handle (HW11) and Screw M4x25 mm (HW12) into Door.



STEP11: Use Wedge (HW16), Screw M3.5x15.5 mm (HW14) to tighten the back of media stand by using screwdriver. Align the top board and bottom board in 90° position against the side board, before securing the wedges (HW16).



Step10: Slide in the door and insert the Sliding Top (HW8) pin into the groove of Top Board. Position the Sliding Bottom (HW9) into the grooved sliding track. Adjust gap of the door by scrolling the button on Sliding Roller (HW9). Follow the down and up direction. Slide the door to the right and left, ensuring the door has been placed properly in the provided track.



STEP12: Assembly is complete.

TIPPING RESTRAINTS KIT INSTALLATION GUIDANCE

Different wall materials require unique wall fasteners.

The wall plugs (AA2) and screws (AA3) are designed for fixing to concrete walls only.

Please consult your local hardware store to ensure you are using the correct hardware for your wall type.

