


TEAMSON HOME

VERSANORA
Boomerang L Shaped Desk

VNF-00114







^{**} Got questions? Please have your product code (on the first page of this instruction, e.g. TD-12345A) and the order number ready, give us a call or email us through our customer care support! We are always ready to assist you!

TEAMSON HOME



Warranty sign up

www.teamsonhome.com

Serving you well gives us great joy!

USA +1(800)935-3959

Mon - Fri 10:00am ~ 2:00pm EST ⊠ support@teamson.com

EU ····· +44(0)1952-916-050

Mon - Thu 9:00am ~ 5:00pm GMT Friday 9:00am ~ 4:00pm GMT

ASIA··· 深圳办公室:

+86(0755)8885-3558.分机号108

Mon - Sat 9:00am ~ 5:00pm GMT+8

⋈ sales_ec@teamson.com


台北辦公室:

+886(2)2556-6268

Product Parts

VNF-00114

PARTS LIST






Care Instructions

Dust surface with a dry soft cloth.


Do not use window cleaners or cleaning abrasives as they will scratch the surface and could damage the protective coating




Small parts and sharp edges may be present prior to assembly.




Step 2





Step 4



Exploded Drawing

FULL ASSEMBLY

