



Stainless Steel Backsplash (24 x 30 Inch)
Model: DYBZW3024



⬇ *6
⬇ *6
⬇ *13

Stainless Steel Backsplash User Manual

Product Introduction:

Thank you for choosing our Kitchen Stainless Steel Backsplash! This product is a beautifully designed and highly practical kitchen accessory, used to protect your walls from grease splatters and stains during cooking. The splash guard measures 30*24 inches, making it suitable for most kitchen environments.

Important Notes:

The side with the film is the front, and the side without the film is the reverse. Use on one side. Please tear off the protective film after the installation is complete.

This splash guard is intended for kitchen use only and is not suitable for other environments.

During cleaning, maintenance, or installation, ensure that power is disconnected and handle with care to prevent accidents.

Avoid using overly harsh cleansers that might damage the splash guard's surface.

Contact Information:

If you encounter any issues during installation, usage, or maintenance, please feel free to contact our customer service team. We are here to assist you.

After-sales Service Team Email: support@ekonkitchen.com

Installation Steps:

1.Preparation: Before beginning the installation, ensure you have sufficient time and the appropriate tools including a ruler, pencil, screwdriver, screws, etc. Make sure your wall is flat, dry, and clean to ensure a secure attachment of the splash guard.

2.Measurement and Marking: Use a ruler and pencil to measure the desired installation position for the splash guard. Mark the positions of all four corners to ensure accurate placement on the wall.

3.Install the Splash Guard: Place the splash guard on the marked positions, ensuring it fits snugly against the wall. Use a screwdriver and screws to secure the splash guard to the wall. Choose screws and installation methods suitable for your wall type (such as brick, wood, drywall) to ensure a sturdy installation. Please remove the plastic film after installation.

4.Check and Adjust: After installation, carefully check if the splash guard is level and secure. If necessary, make minor adjustments to ensure optimal alignment with the wall.

Usage and Maintenance:

Protective Function: This splash guard effectively prevents grease splatters and stains during cooking, providing protection for your walls. It is particularly effective during high-temperature cooking methods like frying, sautéing, and deep frying.

Cleaning Method: The splash guard's surface is made from easy-to-clean material. You can use a damp cloth or mild cleanser to wipe the surface clean. Avoid using abrasive sponges or brushes that might scratch the surface.

Maintenance Tips: Regularly check the secure attachment of the splash guard. If you notice any loosening or detachment, perform repairs promptly. Additionally, avoid impact from sharp objects to prevent scratching or damaging the surface.