


Cannes KD Carver Chair incl. cushion

Assembly Instructions

Product size:
W59*D61*H90.5 cm



**Furniture should be covered/stored whilst not in use to prolong its longevity.
(It should also be covered in adverse weather.)**

This product is for Domestic use only!

**IMPORTANT, RETAIN FOR FUTURE REFERENCE
READ CAREFULLY**

Cannes KD Carver Chair incl. cushion

Before you start



Warnings

IMPORTANT, RETAIN FOR FUTURE REFERENCE READ CAREFULLY

See enclosed instructions for assembly, safety and care information.

Failure to follow the warnings could result in serious injury.

Handle heavy parts with care.

Ensure that this product is fully assembled as illustrated before use.

This product should only be used on firm, level ground.

Keep small parts out of reach of children.

Do not stand or climb onto this product.

This product is intended for **domestic use** only.

Ensure the product is always placed on level ground.

Furniture can be dangerous if incorrectly used. No liability will be accepted for damage or injury caused by incorrect use of this product.



Dos

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packaging materials and place the components on suitable surface to prevent scratching your product.

Check the pack and make sure you have all parts listed. In the event of problems or missing parts, please contact the seller.

Check all screws and bolts are tightened and inspect regularly. We recommend the use of furniture covers to protect your product when not in use.

This product is suitable for all year outdoor use, but we recommend that a furniture cover be used to add additional protection to your product when not in use.

PLEASE NOTE - All cushions should be stored indoors after use. The cushions are not waterproof.

During severe weather conditions and in the winter months we recommend moving your furniture inside into a cool, dry place.

Before storage, ensure that the product is clean and dry.

To clean, wipe down with a sponge and warm soapy water and

wipe with a clean, dry cloth.



Don'ts

Never tilt the chair during use.

Do not stand or climb onto the product.

Do not use power tools to construct this product.

Do not sit or lean onto the rims of this product.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaner.

Do not use this product as a ladder as this could lead to the product becoming unbalanced and overturning.

Never drag furniture when moving it, always lift it.

Number of people required for assembly

One person



Time to assemble



20 minutes

Tools required



Tips:











It is best not to fully tighten the nuts and bolts until they are all correctly located.

Only carefully tighten them when you are satisfied with the alignment of all components.

Be careful not to overtighten.

Cannes KD Carver Chair incl. cushion

Components, fixtures & fittings (not actual size)

Parts List					
Part No.	Diagram	Qty	Part No.	Diagram	Qty
A	 Backrest	2 PCS	B	 Front Leg	2 PCS
C	 Left Armrest/Leg	2 PCS	D	 Right Armrest/Leg	2 PCS
E	 Seat Panel	2 PCS	F	 Cushion	2 PCS
F1	 Spanner	1 PC	F2	 Bolt Head Cap	12 PCS
F3	 Washer	12 PCS	F63	 M6*20mm Bolt	12 PCS

Please note the diagram is for reference only, it may not fully represent the actual appearance of the parts.

The quantity marked is for 2 PCS Chairs.


Cannes KD Carver Chair incl. cushion

Step by step assembly instructions

Step One


Align Backrest (A) with Right Armrest/Leg (D).
Carefully insert the tubular mating part of
Right Armrest/Leg (D) into the end of
the tube on Backrest (A).

Connect the Backrest (A) and Right Armrest/Leg (D)
using Washers (F3) and Bolts (F63).
Make sure all bolts are in place and turn freely.
At this stage, don't tighten the bolts.




Step Two

Repeat above steps for Left Armrest/Leg (C) as shown.



Step Three


Place the sub assembly from above onto
Front Leg (B) as shown.



Cannes KD Carver Chair incl. cushion

Step Four

Turn the partly-assembled chair upside down. Locate assembly holes, connect all parts using Washers (F3) and Bolts (F63). Make sure all bolts are in place and turn freely. At this stage, don't tighten the bolts.



Step Five

Turn the partly-assembled chair to the upright position. Push Seat Panel (E) into place as shown.




Step Six

Turn over the partly-assembled chair. Fix the Seat Panel (E) in place using Washers (F3) and Bolts (F63).

Once you are satisfied with the alignment of all components, carefully tighten all bolts using Spanner (F1).


Do not over-tighten.
Cover each Bolt Head with Bolt Head Cap (F2).



Cannes KD Carver Chair incl. cushion

Step Seven


Level the chair with pre-fitted adjustable foot.




Step Eight

Place the Seat Cushion (F) onto the Seat Panel (E).

Your chair is now ready for use.





Never tilt the Chair during use.
Ensure the product is always placed firmly on the ground.



PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Assembly Instructions - Please keep for future reference



No. People	Assembly Time
	10 - 15 Minutes

Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the next pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drills/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.



Care and Maintenance


- Please clean using cloth with glass cleaner, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.



Warning





Important - In order to help prevent overturning, this product must be used on the level ground.

- To help prevent product toppling over please follow the below steps:
- Use this product on the level ground.
- Do not allow children to climb or hang on the furniture.
- Do not place heavy items on top of the furniture, unless the furniture has been designated for this purpose.








Components - Products Parts

Please check that you have all the components listed below before constructing your item.


Part No.	Diagram & Description	Qty.	Part No.	Diagram & Description	Qty.
A	 <p>Table Top (Diagram is for reference only)</p>	1	B	 <p>Table Leg</p>	2
C	 <p>Connecting Panel</p>	2	D	 <p>Glass Top</p>	1

Components - Fixings

Please check that you have all the components listed below before constructing your item.


Part No.	Diagram & Description	Qty.	Part No.	Diagram & Description	Qty.
F2	 Bolt Head Cap	12	W25	 M6*25mm Bolt	12
F3	 Flat Washer	12	F4	 Spring Washer	12
S1	 Spanner	1			

Tools Required




Spanner

Ruler - Use this to measure your screws (mm)



Assembly Instructions

It is important that all hardware is loosely fitted until the final screw is inserted. If screws are fully tightened before final assembly then alignment may not be accurate.




Step 1

- Open the packaging with the glass face down on a flat surface.
- Leave the glass on the carton until the rest of the table is fully assembled.
- With the help of another person, place Table Top (A) upside down on a flat, non-abrasive surface to avoid scratching the table surface or rim.


Step 2

- Loosely attach the Table Legs (B) to the Table Top (A) using Bolt Head Caps (F2), Bolts (W25), Spring Washers (F4) and Flat Washers (F3).

It is important that all hardware is loosely fitted until the final screw is inserted. If screws are fully tightened before final assembly then alignment may not be accurate.



It is important that all hardware is loosely fitted until the final screw is inserted. If screws are fully tightened before final assembly then alignment may not be accurate.




Step 3

- Loosely attach the Connecting Panels (C) between the Table Legs (B) using Bolt Head Caps (F2), Bolts (W25), Spring Washers (F4) and Flat Washers (F3).
- Once you are satisfied with the alignment of the components carefully tighten all bolts using Spanner (S1).
- Do not over-tighten.
- Cover each bolt with Bolt Head Cap (F2).

Step 4

- With the help of another person, carefully turn the table in the upright position.
- Level the table by adjustable feet screw.
- Carefully place the Glass Top (D) on the Table Top Frame (A) and make sure they are aligned.
- Your table is now ready for use.



adjustable feet screws

Care and Cleaning:

1. To clean, wipe with damp cloth. Do not use bleach, acid solvents or abrasive cleaners for frame parts.
2. During varying weather conditions and winter period, we strongly recommend that it can be stored in a dry area with a suitable cover, pls insure it is clean and dry before storage.
3. In the event of bare metal showing due to scratch, it is preferred to treat with a rust repelling varnish or similar.
4. Periodically check and ensure that all the screws are completely tightened.
5. A matching furniture cover is strongly recommended to extend the usage lifespan.