



Titan Cleaning Instructions

Titan must not be cleaned with any petroleum based cleaners. If any petroleum fuels are spilled on the matting, it should be cleaned immediately to avoid damage to the matting and voiding of warranty.

Initial Cleaning after installation

- For interlocking mats, initial cleaning can be performed immediately after installation.

Regular Maintenance

- **Titan** may be cleaned at any time using a damp mop with a PH neutral cleaner diluted with water.
- Ensure that any moisture is immediately extracted after cleaning.

Precautions

- **Titan** must not be cleaned with any petroleum based cleaners. If any petroleum product is spilled on the matting, it should be removed immediately to avoid damage to the matting and voiding of warranty.

Protection

- While Titan products are designed to be dent, impact and scratch resistant, we recommend that when putting under equipment, care is taken to prevent and minimize dragging of the equipment to prevent scratches and gouges from developing.
- Provide ventilation to installation area during installation and for minimum 72 hours after completion of work.