



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



Avant de Commencer

- ⚠ Veuillez lire attentivement toutes les instructions.
- ⚠ Conservez les instructions pour vous y référer ultérieurement.
- ⚠ Vérifiez toutes les pièces et les accessoires.
- ⚠ Lisez attentivement chaque étape et suivez l'ordre correct.
- ⚠ Nous recommandons que, dans la mesure du possible, tous les produits soient assemblés à proximité de la zone où ils seront utilisés, afin d'éviter tout déplacement inutile du produit une fois assemblé.
- ⚠ Placez toujours le produit sur une surface plane et stable.
- ⚠ Conservez toutes les petites pièces de ce produit et les matériaux d'emballage hors de portée des bébés et des enfants, car ils pourraient présenter un risque d'étouffement.

Before you begin

- Read all instructions before set up.
- Select a level site clear of rocks, branches, and other hard or sharp objects, to install your tent.


WARNING: Keep clear of overhead power lines.

- Do not set up your tent under trees because of potential lightning strikes or falling tree limbs in inclement weather.
- Secure with all stakes and guylines provided to prevent property damage or personal injury.
- For the best results in windy conditions, position narrow end of tent into the wind.
- Do not drop tent.
- Do not bounce tent bag on its end to remove the tent, as these actions may damage the frame.
- Under no circumstances should this product be used to cover automobiles, marine products or similar items.

CAUTION: Avoid pinch points when opening and closing the tent frame.

Contents in Handy Bag

- | | | | |
|--|---------------------------|----------------|-----------------|
| 1. Rainfly*1pc | 2. Tent *1pc | 3. Stake*16pcs | 4. Guyline*8pcs |
| 5. FRP Pole A (Yellow) *1pc | 6. FRP Pole B (Grey)*2pcs | | |
| 7. ST Pole D (marked Yellow)*2pcs | | | |
| 8. ST Pole E (marked Red)*4pcs | | | |
| 9. Supporting Pole*2pcs | | | |
| 10. ST Pole C (marked Blue)*2pcs (NOTE: Only the M and L sizes have this pole; the S size does not) | | | |




Step 1: Extend the Tent Frame

- Remove all contents from bag.
- Assemble all poles and spread out the tent.

Step 2: Insert FRP Poles


- Insert the assembled FRP pole A (Yellow) through the pole sleeves located on top of the tent, repeat this process with the remaining FRP poles B (Grey) through sleeves.
- Poles will cross each other at center. Tie center loops to connect tent poles.

- Insert the FRP pole end into **plastic connectors** on the tent.
- Note:** The S size tent has 2-way connectors in the four corners, while the M and L size tents have 3-way connectors.



Step 3: Insert the ST Poles

- Insert one end of the ST poles into the plastic connector, and the other end of the ST poles into the metal ring corresponding to the six corners of the tent (as shown in the picture).
- FRP poles A connected with ST poles D, and FRP poles B connected with ST poles E.
- NOTE:** For M and L size tents, please remember to insert the ST poles C into the 3-way connector.




Step 4: Secure Tent to Poles

- Locate plastic hooks on the tent and clip them onto ST poles.



Step 5: Attached Rainfly

- Drape rainfly over the tent.
- Fix the hook and loop fasteners to the ST tubes.
- Insert plastic clip on web strap on rainfly into buckle connector located on web strap at base of leg pole. Repeat for remaining leg poles.




Step 6: Stake the Tent, Secure the Guylines

- Drive stakes at a 45° angle through web loop at base of tent to secure to ground.
- Floor of tent should be taut when staked properly.
- Locate guylines attached to the rainfly.



- Stake out each guyline at a 45 degree angle.
- Tighten guylines as needed by adjusting the slider up the cord.



TAKE DOWN INSTRUCTION:

To take down the tent, follow the previous steps and illustrations in the reverse orders:

- Remove all stakes from the tent and guylines. Store in stake bag.
- Unhook plastic rainfly clips from foot connector of leg poles.
- Detach the rainfly, and set aside.
- Unfasten plastic hooks from poles.
- Remove end of tent poles from the metal pin on pin ring at each corner of the tent and allow tent to lay flat.
- Remove the tent poles by carefully pushing them through the sleeves away from the end at which you are standing.
- Disassemble all poles and place them together.
- Fold tent lengthwise 2-3 times. Then lay all the poles on short edge of tent, and roll tent around poles.
- Store in the carry bag with rainfly and bag of stakes.

To Store

1. All stakes must be placed in the storage bag to prevent damage to the fabric items placed in the carry bag.
2. Make sure all components are clean and dry before placing in carry case.
3. Store in a clean, dry area.

Things You Should Know:

- Under certain conditions (cold weather, high humidity, etc.), condensation will form on the inside of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside the tent. It is NOT LEAKAGE through the tent fabric.
- Tree limbs, tree sap, bird droppings, or moisture steadily dripping off tree limbs can cause damage to the tent fabric and its coating resulting in leaks or loss of flame-resistant properties.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes inside your tent. Use a separate storage bag.
- Stakes should be removed by pulling on the stake itself. **NEVER PULL ON THE TENT TO REMOVE STAKES AS THIS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.**
- Do not leave your tent set-up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.
- This product is not intended to be used during heavy rain, wind, hail, snow or other inclement weather. Excess water build-up can cause the frame system to become unstable, and possibly collapse, causing injury.
- The tent should be taken down and placed in storage during windy conditions to avoid damage to product or personal injury.
- DO NOT use gas or flame sources under or near this product.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.