

Adjustable Height & Angle Reading Stand

OVERVIEW:

Your new reading stand “accordions” up and down, holding books, tablets and screens at a comfortable viewing angle.

- Each stand has 2 legs.
- Each leg has 3 segments.
- Each segment is connected with a push-button joint.

To operate a joint, depress the button and rotate the leg to the desired angle

Once the button is depressed, joints rotate in a complete circle or 360°.

The joint is locked when the button is extended. Only use WorkEZ when all joints are locked.



Depress the button to adjust the leg.



An extended button means the joint is locked.

JOINT MEASUREMENTS:

Joints lock in ~15-degree increments (marked with the numbers 0 to 23). Each joint button has an arrow that points to the locked setting.



For Each Leg:

- A.** JOINT A = outside joint, farthest from the panel.
- B.** JOINT B = middle joint.
- C.** JOINT C = inside joint, connected to the panel.


Recommended joint settings to help you set up your stand

| USE | JOINT A | JOINT B | JOINT C | | |
|--------------------|---------|---------|---------|------------------|--|
| Seated at a desk | 0 | 22 | 9 | Repeat for Leg#2 | |
| Standing at a desk | 23 | 18 | 17 | Repeat for Leg#2 | |
| Bed/Couch | 13 | 21 | 17 | Repeat for Leg#2 | |

Your stand has a seemingly infinite number of configurations. Feel free to adjust the stand to any height or angle you'd like. Be sure that all joints are locked and the stand is stable before use.

Customizing the Panel Angle

Simultaneously pressing the same joint on each leg lets you quickly and evenly adjust the platform angle or height



Push both buttons

To COLLAPSE your stand:

1. Fold JOINT C to 0°
2. Fold JOINT B to 0°
3. Fold JOINT A to 0°