






3 Pieces Wicker Rocking Chair Set

Assembly Instructions




- Prior to assembly, make sure to lay out and identify all of the parts listed below in the parts list.
- Please do not completely tighten the screws during assembly. Recommend to use allen wrench for assembly.
- Should you experience any difficulty during assembly, or if any of the parts are missing or damaged, please feel free to contact us.

A  1X	B  1X	C  1X	D  1X
E  12X	F  M6*16 6X	G  M6*30 6X	H  12X
I  1X	J  1X	K  1X	


Step 1

Connect legs (part A&B) and seat(part C).




Step 2



Connect back (part D) and legs.




Step 3

Put the back cushion(part K) and seat cushion(part J).




A  1X	B  1X	C  1X	D  4X
E  12X	F  M6*16 4X	G  M6*22 8X	H  12X
I  1X			


Step 1 Connect table top(part A) and legs(part D).



Step 2 Connect legs using the support bar(part C).



Step 3
Put glass(part B) on the table top.





RESORT COMFORT IN YOUR OWN BACKYARD

Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So if you have any questions about our product and assembly, please feel free to contact us. We will be here for you.

Support:



email: domiservice03@outlook.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.