


# EASTMAN®

## Icemaker Outlet Box Installation Instructions



- |   |
|---|
| 1) Remove the faceplate that is attached to the ice maker box and save for future installation.   |
| 2) Using either nails or screws, mount the box to the stud via the flanges on the side of the box.<br>Hammer in the pre-loaded nails to the stud for a stronger hold. |
| 3) Box can be mounted:  |
| a) On either side of the stud bay.  |
| b) At a height determined by builder/installer.   |
| c) In any direction - top mount, etc.   |
| 4) Connect the water supply tubing to the ice maker box valve via crimp PEX connection.   |
| 5) Check all local codes for appropriate approvals and requirements.  |
| 6) To the 1/4" outlet of valve attach either:   |
| a) Copper supply tubing via compression connection.   |
| b) Poly supply tubing via compression connection - brass insert into poly tube is required  |
| c) Braided hose via threaded connection.  |
| 7) Connect to the inlet connection of the refrigerator.   |