

## ASSEMBLY INSTRUCTIONS - SINK BASE CABINET







This instruction applies to the following items:

SB30 (Single false drawer)


SB36 (Double false drawers)


## ASSEMBLY INSTRUCTIONS - FARM SINK BASE CABINET







This instruction applies to the following items: FSB36






## ASSEMBLY INSTRUCTIONS - FULL DOOR BASE CABINET







This instruction applies to the following items: FDB18-FDB36




#### **ASSEMBLY INSTRUCTIONS - BASE CABINET**







This instruction applies to the following items: B09、B12、B15、B18、B21、B24、B27、B30、B33、B36、B39、B42




## ASSEMBLY INSTRUCTIONS - DRAWER BASE CABINET (2 DRAWERS)



This instruction applies to the following items:  $2\mathrm{DB30},\,2\mathrm{DB33},\,2\mathrm{DB36}$ 




# ASSEMBLY INSTRUCTIONS - DRAWER BASE CABINET (3 DRAWERS)




This instruction applies to the following items: DB12、DB15、DB18、DB21
DB24、DB27、DB30、DB33、DB36


#### ASSEMBLY INSTRUCTIONS - BLIND BASE CORNER CABINET





This instruction applies to the following items: BBC33-9




#### ASSEMBLY INSTRUCTIONS - LAZY SUSAN CORNER CABINET









This instruction applies to the following items: LZS33  $\,$  LZS3612




## ASSEMBLY INSTRUCTIONS - BASE MICROWAVE CABINET




This instruction applies to the following items:  ${\rm BMC30}$ 




## ASSEMBLY INSTRUCTIONS - BASE WASTE BASKET CABINET



This instruction applies to the following items:  $\ensuremath{\mathsf{BWBKT18}}$ 



## ASSEMBLY INSTRUCTIONS - WALL CABINET (WITHSHELVES)




This instruction applies to the following items:


 W1224-W2724
 W0930-W2130
 W2430-W3630

 W3024-W3624
 W0936-W2136
 W2436-W3636

 W302427-W362427
 W0942-W2142
 W2442-W3642




# ASSEMBLY INSTRUCTIONS - WALL CABINET (WITHOUT SHELVES)




This instruction applies to the following items:

W2412-W2418 W3012-W3612 W301227-W361227 W


W3015-W3615 W301527-W361527 W3018-W3618 W301827-W361827




## ASSEMBLY INSTRUCTIONS - WALL DIAGONAL CORNER CABINET




This instruction applies to the following items: WDC243012,WDC243612,WDC244212




## ASSEMBLY INSTRUCTIONS - WALL BLIND CORNER CABINET




This instruction applies to the following items:  $\ensuremath{\mathtt{WBC2730-\mathtt{WBC2742}}}$ 




## ASSEMBLY INSTRUCTIONS - WALL MICROWAVE CABINET







This instruction applies to the following items:  $\ensuremath{\mathtt{WMC3018}}$ 




## ASSEMBLY INSTRUCTIONS - WALL WINE RACK CABINET






This instruction applies to the following items:  $\ensuremath{\mathsf{WRC3018}}$ 



#### ASSEMBLY INSTRUCTIONS - WALLPANIRY CABINET



This instruction applies to the following items: WP188427,WP248427,WP189027,WP249027,WP189627,WP308427,WP309027,WP309627,