



Product Name:	34in Wood Rectangular Raised Garden Planter
SKU #:	WHPL885

Thank you for purchasing this Luxen Home product. This product has been manufactured with the highest standards of safety and quality.

### PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

### **CARTON CONTENTS:**

Part	Draw	Quantity
1	· · · · · · · · · · · · · · · · · · ·	4
2		2
3		2
4		1
5		2





Product Name:	34in Wood Rectangular Raised Garden Planter
SKU #:	WHPL885

6	3
7	4
8	1

## **HARDWARE CONTENTS:**

Part		Quantity
A	① <del></del>	24
В	( <del>)                                    </del>	4
С	<b>()</b>	8
D		4
E	f) - 100000000000000000000000000000000000	4


Tools required for assembly: Philips screwdriver (if using power tools, use with care)

Do not completely tighten any bolts until the unit is fully assembled and sitting on a level surface. Tighten each bolt nuts firmly. Do not over tighten any bolt nuts as this may cause stripping.


Product Name:	34in Wood Rectangular Raised Garden Planter
SKU #:	WHPL885

## **Assembly Instructions:**

**Step 1** Insert each (1) on both ends of (2). Align and screw in (A).




**Step 2** The other side of (1), insert each (3). Align and screw in (A).






Product Name:	34in Wood Rectangular Raised Garden Planter
SKU #:	WHPL885

Step 3 Insert each (1) on both ends of (2 and 3). Align and screw in (A).




Step 4 Turn upside down, place (4) to (2). Align and screw in (B).






Product Name:	34in Wood Rectangular Raised Garden Planter
SKU #:	WHPL885

**Step 5** Place (5) at each end and (6) in the center.




**Step 6** Insert (D) to each corner. Insert (7) to each corner. Align and screw in (C).





Product Name:	34in Wood Rectangular Raised Garden Planter
SKU #:	WHPL885

Step 7 Place (8) at an angle and set in the center. Align and screw in (E) bolt and secure with nut.



# **Special Warnings and Cautions:**

To avoid injury and/or damage, please do not sit or stand on the planter as this may cause serious bodily injuries and/or product damage.