



FOLDING CHAIR

SETUP AND USE




STEP 1

Place the chair face down with the straps facing upwards and apply downward pressure on the armrest hinges with both hands.




STEP 2

Flip the chair over with the straps now facing down.



STEP 3


Hold the bottom cushion down with one hand. Push the backrest forward and upwards with your other hand. You will hear the chair click and lock into one of the six reclining positions.



NOTE


You can open the chair without the armrests. Simply skip step 1 and ensure that the armrest hinges are bent backwards before locking the backrest into place.

CLOSING THE CHAIR



STEP 1

Hold the bottom cushion down with one hand and push the backrest forward with your other hand until the reclining lock is released.



STEP 2

keep holding the bottom cushion down with one hand while you fold back the backrest into its horizontal position.

CARE AND WARNING

Keep away from flames or heat sources.
Use with caution when handling sharp objects.

The removable cover must only be hand washed.
Do not machine wash the removable cover.