


WARNING!

When unpacking the mattress, stand back from the direction in which it expands. Exercise caution to avoid possible injury.



Carefully remove the outer packaging
Carefully remove the outer packaging film. Do not use a knife, as this may damage the mattress.



Place the mattress
Place the compressed mattress on a clean, flat surface.



Open the plastic bag
Carefully cut open the plastic packaging bag on both sides.



Beware of Rebound



Beware of Suffocation

PACKAGING IS NOT A TOY!

KEEP THIS BAG OUT OF REACH OF BABIES AND CHILDREN.
DO NOT USE IT IN CRIBS, BEDS, CARRIAGES, OR PLAYPENS.
THIS BAG IS NOT A TOY. DISPOSE OF IT PROPERLY BEFORE DISCARDING.

UNPACKING GUIDE

- Warranty: 10 years
- Customer Support: home@homeselecting.com

- Care Instructions
- A slight odor from the new mattress is harmless and will dissipate after a short time.

