

PLEASE DO NOT RETURN TO THE STORE!

Missing or damaged parts? Contact us for free replacements and get an extra 6-month warranty. E-mail:Nicesure-aftersales@outlook.com.

ASSEMBLY INSTRUCTION:

1.Initial Tightening

Use a hex key (Allen wrench), not a power drill, to tighten each screw to about 50% before fully securing any of them. Fully tightening one screw too early may cause others to misalign.

2.Final Tightening

Once all parts are aligned, gradually and evenly tighten all screws using the proper tools.

3.Misalignment Fix

If some screws don't line up, loosen all screws to 50%, adjust the parts, and try again.

4.Stability Issue

If the item feels unstable, loosen all screws, adjust it on a flat surface, then retighten them evenly.

Hardware Fittings

ltem No.	Reference Image	Description	Qty.	Extra Spare Parts Qty.
A		screw M8*40	4	1
В		screw M8*35	8	1
С		spring washer for M8	12	1
D	\bigcirc	nut for M8	12	1
E	\bigcirc	washer for M8	12	1
F	(D)	Screw cap	12	1

ltem No.	Reference Image	Description	Qty.	Extra Spare Parts Qty.
G		Adjustable foot pads	4	1
Н		allen key for M8	1	0
I		Spanner for M8	1	0
J				
к				
L				

