

USE AND CARE MANUAL

FLOOR LAMP WITH NIGHT LIGHT Model number: 21293



Hardware (Parts are not to scale)



THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water
 or other liquids.
- Never cover the lamp with any object including cloth or paper as this is a fire hazard.
- Do not handle the bulb immediately after the light is turned off as it will be hot.
- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

PREPARATION

Before beginning assembly, installation or operation of product, make sure all parts are present. Compare
parts with package contents list and diagram on previous page. If any part is missing or damaged, do not
attempt to assemble, install or operate the product. Contact customer service for replacement parts.


ASSEMBLY

SHADE ASSEMBLY

1 Assembling the shade

- Place the shade panel (H3) and top ring (H4) and bottom ring (H5) from the box.
- Attach the top ring (H4) and the bottom ring (H5) to clips on the shade panel (H3) securely into the clips.
- Attach the shade panel (H3) together by velcro.

NOTE: Push and pull the shade panel (H3) to be tight before attach it together by velcro.




ASSEMBLY (continued)

LAMP ASSEMBLY

1 Assembling the tubes onto the base

- Pull the excess power cord through the base (F).
- Tighten the lower tube (E) onto the base (F).
- Tighten the middle tube (D) onto the lower tube (E).
- Tighten the upper tube (C) onto the middle tube (D).

NOTE: Do not twist the power cord.




2 Assembling the socket assembly to the upper tube

• Pull the excess power cord through the base (F).


 Tighten the socket assembly (A) onto the upper tube (C).

NOTE: Do not twist the power cord.



3 Assembling the harp


• Insert the harp (H2) prongs into the saddle of the socket assembly (A) and slide the retaining covers over joints to secure the harp.



4 Installing the upper light bulb

 Install the light bulb (H8) into the socket. Use one MAX 16W medium base (E26) self-ballasted LED bulb (9.5 W medium base (E26) self-ballasted LED bulb (H8) included).

NOTE: You can also use one MAX 150W medium base (E26) type "A" bulb. Do not exceed the recommended wattage.




ASSEMBLY (continued)

LAMP ASSEMBLY

5 Assembling the shade

- Unscrew the finial (H1) from the harp (H2).
- Place the shade assembly onto the harp (H2) and secure with the finial (H1).


NOTE: Grasp the finial (H1) to adjust the shade assembly to level if shade is skewed. Remove the plastic cover from the shade before using.



6 Installing the night light bulb

- Unscrew the cap nut (H6) from the screw of the socket assembly (A) and remove the frame (B) from the socket assembly (A).
- Install the night light bulb into the socket. Use one Max 9W medium base (E26) self-ballasted LED bulb (2W LED bulb (H7) included).
- Tilt the frame and place the frame (B) over the night light bulb and let the screws of the socket assembly through the holes of the frame (B), then secure with the cap nuts (H6) as shown in diagram.


NOTE: You can also use one MAX 40W medium base (E26) type "T" or type "A" bulb. Do not exceed the recommended wattage.



ASSEMBLY (continued)

LAMP ASSEMBLY

7 Using the floor lamp



CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

TROUBLESHOOTING

- The light does not come on at all:
 - a) Ensure whether the bulb is burned out.
 - b) Ensure the power supply is turned on.
 - c) Ensure the cord is plugged into an outlet.
 - d) Ensure the circuit breaker is set in the "ON" position.
- Fuse blows or circuit trips when light is turned on.
 - a) Check for crossed wires, ensure wiring is correct.

