


ASSEMBLY INSTRUCTIONS

CORNER SOFA SET



WF325474AAE

WF325476AAE

WF325475AAE

WF325477AAE

WF325474AAE


Ⓐx1

Ⓑx1

Ⓒx1

Ⓓx2

Ⓔx8




WF325476AAE

Ⓕx2

Ⓒx1

Ⓓx2

Ⓔx8




WF325475AAE

Ⓖx2


Ⓒx1

Ⓕx10




WF325477AAE

Ⓒx3




Part List:

A x1




B x1




F x2




G x2



C x6



D x4




E x16




F x10



STEP1




STEP2




STEP3

x2




STEP4

x2



STEP5



STEP6

