
vanity unit

E151-031-001

V-1-1



Thank you for choosing our products. We are committed to profviding excellent customer service and support. Please feel free to reach out to us with any inquiries or assistance you may need.



: home@homeselecting.com

M WARNING

Children have died from furniture tipovers. To reduce the risk of furniture tip-over.

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place the heaviest items in the lowest drawers.



IMPORTANT SAFETY NOTICE READ CAREFULLY BEFORE BEGINNINGASSEMBLY

- This cabinet contains small parts that present a choking hazard for children under 3 years of age. Adult assembly only. Secure parts permanently to furniture. Discard any unused parts properly.
- To make the assembly process easier, ask a friend to help you.2 people required.
- Always use proper tools. Avoid using a electric drill excessively to prevent damage to cabinet components, especially in wooden furniture.
- Carefully review the parts and hardware list.
- Recommend assembling the storage cabinet on a protected or carpeted surface to prevent scratches.
- Follow assembly steps in order. DO NOT SKIPANY STEPS.
- Regularly check and tighten all connectors (bolts, screws, etc.). Keep instructions for future reference.
- Exercise caution with sharp edges during assembly and use to avoid scratching or cutting the skin.


CARE AND CLEANING GUIDELINES

Congratulations on your new purchase! Follow these simple care instructions to keep your product in top condition:

- Use a soft, clean cloth that will not scratch the surface when dusting
- Wipe clean using a damp cloth and a mild cleaner.
- Liquid spills should be removed immediately.
- Direct sunlight may fade or alter the color of wood finishes.

EXPLODED DRAWING: A . 10


PARTS:




A. x7PCS


T. x1PC


2





C. x2PCS











J. x2PCS

K. x4PCS




INSTALLATION STEPS

Press the plastic part in the indicated direction to separate drawer runner N1 and N2 before assembling.

REMARK:

Please grip the N1 part while sliding the N2 part




N. x2SET


N1. x4PCS


P. x8PCS


12





8






































🐠 O. x8PCS


38




Q. x4PCS








M. x4PCS







If a part is missing or damaged please fee free to contact us via custom service email

home@homeselecting.com

We will gladly ships your replacement parts FREE of charge