INSTALLATION INSTRUCTIONS

Item# 2413-695-L 2414-695-L (New.07/07/2024)

READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

PREPARATION (Fig. 1)

- 1. Shut off power at the fuse box or circuit breaker box and remove the old fixture including the mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts in a clean area. Take care not to misplace any small parts necessary for installation.

ASSEMBLING THE FIXTURE (Fig.1)

- 3. Loosen mounting screw (E) to remove mounting plate (B) from backplate (F). Position mounting plate (B) to wall and mark location of four mounting holes. Pre-drill the holes for plastic anchors (A). Insert plastic anchors (A) into wall.
- Attach mounting plate (B) to junction box (Not included) using junction box screws (D). The side of mounting plate (B) marked "GND" must face out.
- 5. Secure mounting plate (B) by threading wood screw (C) through the holes on mounting plate (B) into plastic anchors (A).
- The support cable (L) is provided to support weight of fixture while wiring. Align fixture to mounting plate (B) and attach the hook of support cable (L) into a slot located on mounting plate (B). Carefully allow support cable (L) to support weight of fixture while wiring (Fig.1).

CONNECTING THE WIRES (Fig. 2)

- 7. Connect the electrical wires as shown in Fig.2, making sure that all wire connectors are secured. If junction box has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to mounting plate (B) using the green screw provided.
- 8. Tuck the wire connectors neatly into the junction box.

COMPLETING THE INSTALLATION (Fig. 1)

- Raise backplate (F) and align with the holes on mounting plate (B) and secure with mounting screws (E) (Size: #8-32N*L0.5").
- Attached bracket (K) on glass (H), hang bracket (K) on metal square box (G), then secure with Allen screws (J) using Allen wrench (I) (Provided).

Note: Some glass may need to add a plastic washer (M) to adjust position.

Dimmable with ELV and/or LED compatible wall dimmer switches.

Your installation is now complete. Return power to the junction box and test the fixture.

Note: Illustration (Fig. 1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.

Fig. 1

Set# A-020-130115 for 2413-695-L Set# A-020-160115 for 2414-695-L Mounting Plate x 1pc Ground Screw x 1 pc Junction Box Screw x 2pcs







LA-3279E