

Instruction Manual

AD1009-2PK Table Lamp

Overview

A

B

C

D

E

F

G

1

NO.

Name

A

Bulb E26 (not included)

B

Finial

C

Lampshade

D

Harp

E

Socket assembly

F

Lamp base

G

Power cord

2

Assembly Instruction

1) Pull out the power cord until Socket Assembly reaches Lamp base

2) Rotate Socket Assembly counter-clockwise by two turns

3) Screw Socket Assembly onto Lamp Base

3

4) Insert Harp into Saddle

4

5) Assembly Lampshade as it shows below

1

2

3

5

6) Install Bulb(not included), then put Lampshade onto Harp and tighten it with Finial

6

Product Specifications

Input voltage

120V

Rated power

100W MAX

Lamp socket

E26

Cord length

5 ft.

Overall size

27.5"H X 14"W

Product Packaging

Lampbase X 2

Lampshade X 2

Harp&Finial X 2

Manual X 1

7

Safety Warning:

BULB TYPE:

Use only the bulb type and wattage indicated on Wattage Label placed on or near socket.

WARNIN G: NEVER EXCEED MAXIMUM WATTAGE

Indicated as bulb may cause fire.

CAUTION:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

DO NOT ALTER THE PLUG!

Wide Blade

PROPER LAMP CARE:

Use a soft cloth to dust your lamp on a regular basis.

Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

TROUBLESHOOTING:

If fixture does not work:

1. Turn off electrical power and check all wire connections.

2. Check fuse or circuit breaker and replace if necessary.

3. Check to make sure light bulb is in working order.

CONTACT US

E-mail: service@24h-reply.com

A section 3rd floor C building shengyao industrial zone shicongheng rd

shicong area ShipaiTown DongGuan city Guangdong province China