


SWING CHIAR




ITEM NO.: F90


IMPORTANT
PLEASE READ BEFORE YOU COMMENCE ASSEMBLY
Follow the guidelines in this user guide to ensure correct
assembly and care for this product.

Assembly Instruction


PARTS




HANDWARES



step.1




STEP.2




STEP.3

⑤





⑥




STEP.4


④




STEP.5



STEP.6



STEP.7



⑧

CARE & MAINTENANCE

Depending on the amount of use this product received, it may be necessary to tighten the fixings from time to time. This is normal for any flat pack furniture.

For cleaning, use a damp cloth (not wet), dry duster and normal furniture polish.

Note that the product cannot swing around like a swing, and accidental injuries caused by improper use of the product have nothing to do with our company.

Note:

- Design and specifications are subject to change without notice.
- Weight and dimension shown are approximate.