




Notes:Don't tighten screws completely at first, just in case parts were assembled wrong and need disassembled. Tighten screws at last when all parts are put together.





No.	PICT	SIZE	QTY		No.	PICTURE		SIZE	QTY	
A	(a)))))))))	0	M6*25	4		Н	O)))))))		M6*20	2
В	(1)		M6*30	6		I	•			4
C			M6*40	4		J		2		4
D			ST7*40	30			6666666	22		1
E	A n or	4	M6*35	22						
F	3	4	ST3. 5*14	16						
G	(1) X2	// X1	M4*18	2						1





INSTALLATION INSTRUCTION 20 21) (19) X1 X1 X1 22) 23) 24) X1 X2 X1 26) 25) X2 X1 STEP 1 Ι X4 3 -

















-10-

INSTALLATION INSTRUCTION STEP 23 E 2X E 2X E 2X M6*35 Е X4 STEP 24 22 D ST7*40 X4G M4*18 X1 STEP 25 F ST3. 5*14 F 2X F 2X

