

RECLINER ASSEMBLY INSTRUCTIONS





PART LIST



WARNING

This sofa is designed for one person weighing up to 275lbs(125kgs).

Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Do not place your upholstery furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.

Do not use rough cleaning tool or corrosive detergent to clean the sofa.

Some of the parts are heavy and/or has shape edge, please install it carefully to avoid hurt you and people around you.


• If any parts are missing, broken, damage or worn, stop using the sofa until repairs are made and factory replacement parts are install.

STEP 1:

MATCH BOTH SIE HOOK-LOOP BRACKET ON BACKREST(1) AND MAIN FRAME (2), PUSH DOWN BACKREST (1) TO ASSEMBLY.

STEP 2:

ASSEMBLE FOUR PLASTIC LEGS(3) AND WASHERS (4) TO THE BOTTOM OF MAIN FRAME (2).




STEP 3:

IF YOU WANT TO LEAN BACK, USE YOUR BODY WEIGHT AND ARMS TO PUSH THE BACKREST DOWN.

STEP 4:

CLOSE THE FOOTREST WITH LEGS THEN YOU CAN STAND UP.



MAINTENANCE INSTRUCTIONS

TO STORE:

Place unit in its box or safe, dry, cool place. Avoid contact with sharp edges or pointed objects which might cut or puncture the fabric. Do not wrap power cord around the unit. Do not hang the unit by power cord.

TO CLEAN:

- Insure the unit is unplugged from the power source, and allow to cool before cleaning.
- Do not place in any liquid to clean. Clean fabric cover by wiping with a damp sponge justing

	END	 	