


TV Stand w/ Fireplace

Item: YS-021

Assembly Instruction


NOTE: This instruction manual contains IMPORTANT safety information. Please read carefully before assembling the product

List of Parts



Hardware

A x 58+2




Ø6 x 34mm

B x 58+2



Ø15 x 10mm

C x 18+1




Ø8*30mm

D x 8+1




Ø3*12mm


E x 4



F x 2



G x 2




Ø4*22mm

H x 4+1



Ø3*16mm

I x 2



J x 28+2



Ø3.5*12mm

K x 12




L x 16+1




Ø3.5*12mm

M x 4




N x 2



STEP1

A x 4




Ø6 x 34mm

B x 4



Ø15 x 10mm




STEP2

A x 10



Ø6 x 34mm




STEP3

B x 6




Ø15 x 10mm



STEP4

A x 6




Ø6 x 34mm

B x 6




Ø15 x 10mm



STEP5

A x 2




Ø6 x 34mm

B x 2



Ø15 x 10mm





STEP6

H x 4



Ø3*16mm

I x 2




STEP7

A x 4




Ø6 x 34mm




STEP8

A x 4



Ø6 x 34mm




STEP9

B x 4




Ø15 x 10mm

C x 4



Ø8*30mm




STEP10

B x 4




Ø15 x 10mm

C x 2



Ø8*30mm




STEP11

B x 4




Ø15 x 10mm

C x 2



Ø8*30mm



STEP12

A x 6





Ø6 x 34mm

L x 8




Ø3.5*12mm

M x 4




STEP13

A x 8



Ø6 x 34mm




STEP14

B x 6




Ø15 x 10mm

C x 4



Ø8*30mm




STEP15

B x 8




Ø15 x 10mm

C x 2




Ø8*30mm




STEP16

A x 14



Ø6 x 34mm



STEP17

B x 2





Ø15 x 10mm

D x 8



Ø3*12mm

E x 4




STEP18

B x 12




Ø15 x 10mm

C x 4



Ø8*30mm




STEP19

F x 2



G x 2





Ø4*22mm

D x 4



Ø3*12mm

E x 2




STEP20

L x 8




Ø3.5*12mm



STEP21

K x 12

TV STAND ASSEMBLY




STEP22



J x 28






Ø3.5*12mm




STEP23



Wall



STEP24




STEP25

K x 8



FIREPLACE MANTEL ASSEMBLY




STEP26



J x 16






Ø3.5*12mm




STEP23




Wall



STEP24





FIREPLACE INSTALLATION

If you decide to install the fireplace into the mantel, carefully set the unit from the back of the mantel and center it in the opening.

Check the alignment and attach the unit to the mantel by inserting screws through the drilled holes on the trim to the mantel.

NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.