

INSTALLATION INSTRUCTIONS

ITEM# CT-HL001

OUTDOOR WALL LIGHT 120V No Dimmable

Please read carefully and save these instructions, as you may need them at a later date.

READ AND FOLLOW SAFETY INFORMATION

CAUTION - Turn off the main power at the circuit breaker before installing and servicing the fixture to prevent possible injury from electric shock. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

INSTALLATION AND ASSEMBLY

1. Remove the power cable from the cable box, and secure the installation bracket (2) to the cable box using cable box screws (3). As shown in **Fig.1**.

2.Connect the wires shown in **Figure 2** with the wiring cap (1).


3.Connect a section of the chain (5) to the mounting plate (2), and a section of the chain (5) to the ring (6) with an active interface (7), and adjust the length of the chain (5) according to the lamp (8).

4.Fasten the canopy (4) to the ceiling.

5.Install E26 bulb and turn on power. Test luminaire.

6. Install the glass (9) on the luminaire (8) and fix the bottom box (10) on the luminaire (8) with mounting screws (11) to clamp the glass (9).

Fig.2



- 1.P3Terminal cap
- 2.Mounting plate
- 3.Outlet box screws
- 4.canopy
- 5.Light sling
- 6.Hanging rings
- 7.Active interface
- 8.Lamps and lanterns
- 9.Water grained glass
- 10.Bottom box
- 11.Mounting screw

Fig.1

