


AIRPLUS

USER MANUAL

Ultrasonic Humidifier




AIRPLUS

CONTENTS

SAFETY NOTICE	01-02
PARTS AND COMPONENTS	02
INSTRUCTIONS	03-05
CLEANING AND MAINTAINING	06-07
TROUBLESHOOTING	07
ABOUT WARRANTY	08

SAFETY NOTICE

Please read the instructions for this product carefully before using it. Any operation that does not conform to the contents of the specification may result in serious personal injury or damage to the product itself.



01

AIRPLUS

ABOUT WARRANTY

Q: Do you have a warranty for this product?

A: We strictly abide by Amazon regulations which cover a full refund or a free replacement within 30 days of your purchase. Additionally, if there are any problems with this product, please always feel free to contact us at us.airplus@gmail.com and attach your Order ID to help us solve your problems more effectively. We promise our team always stands behind our product and we will try our best to offer you a better user experience.

08

When not in use for a long time:


- After shutdown, turn off the power switch and pull out the power plug.
- Pour out water in the tank; clean the host and water tank.
- Pack the humidifier in the packing box.
- Store the humidifier upright in a dry and ventilated place.

Reuse after long idle time:

- Clean the host and water tank; add proper amount of water into the water tank.

• Plug in the power cord and turn on the power switch.

Parts And Components



① Lid

② Water Tank

③ Base

④ Control Panel

⑤ Essence Box

⑥ Filter Cotton

⑦ Bottom Cover

02

AIRPLUS

Troubleshooting

Issue	Possible Cause	Solution
Humidifier doesn't work	The power plug is not plugged in properly.	Plug in the power plug.
	There is no water in the water tank.	Add water into the water tank, but do not exceed the max line.
	Water tank is not in place.	Install the water tank in place.
The mist smells weird	The water is dirty, or the water has been in the tank for too long.	Clean the water tank and sink, and replace with clean water.
The humidification effect is not obvious	The air inlet is blocked by dust.	Dust the air inlet.
Abnormal noise appears	The humidifier is not placed horizontally (tilted or unstable).	Place the humidifier on a hard horizontal surface.
There is water in the water tank, but it shows a lack of water.	The excessive inclination of the humidifier causes the water level in the water tank to be too low, and the machine is automatically protected, so it stops.	Place the humidifier on a hard horizontal surface.

Please contact us.airplus@gmail.com if you have any additional questions.

07

Instructions

Power L M H



Button Function

① Power button (1) In standby state, short press (1) to turn on/off the humidifier, high mist level is humidified, by default, and the atmosphere light, Power light and corresponding mist level indicator light are on. (2) When you turn off the humidifier, the atmosphere light will go out.

② Mist level button (1) When you press (1), the mist level will cycle among "Medium" (1), "Medium" (2), "Medium" (3). (2) When you press (2), the mist level indicator light will be according to the mist level you choose.

③ Night light button (1) In the stand-by state, the atmosphere light is not on. Press (1) to turn it on/off. (2) Atmosphere light, press (1) state, second time press (1) to turn off the atmosphere light. (3) When there is no water in the water tank or little water in the base of the humidifier, the atmosphere light will flash for 10 seconds, and the humidifier stops working, pick up the water tank, the atmosphere light flashes for 10 seconds, pick up the water tank, the atmosphere light will go out.

④ If the indoor temperature is too low or the humidity is too high, it is suggested to lower the mist level.

⑤ There is no humidifier water in the base when the water in the tank has not reached the base, or

03

AIRPLUS

Cleaning And Maintaining


Attention:

- Unplug before cleaning.
- The scale and debris in the water tank must be cleaned regularly, and it is recommended to clean it every 2-3 weeks.




Water tank cleaning

Can be directly wiped with a clean soft wet cloth.



Sink and atomizer cleaning

Add clean water, and rinse after cleaning.



Essence cotton and filter cotton cleaning

Soak the essence cotton and filter cotton with water and dry them. The essence box, clean them with water and dry them.



Essence box cleaning

Clean the essence box with water and dry it.

06




Use

Attention:

- Please pull out the power plug before adding water.
- Do not directly pour water into the mist nozzle or base to prevent electric shock.
- Do not add additives in water, such as essential oils, perfumes, drugs, etc.
- Use clean water or purified water with water temperature lower than 104 °F (distilled water is not suitable).

Steps to add water (Three methods)


For the first time, it is recommended to use the first method to add water.




04

AIRPLUS

Water tank installation



When the water tank is installed, the mist control panel should be installed on the same side.



Mist direction adjustment

The direction of fog release can be adjusted by turning the cover for 90 degrees of rotation.

05