

Installation Manual-BV B03560



THANKS FOR WATCHING

Your feedback is invaluable to us and we would love to hear about your experience. Please take the time to leave us a review.






Thank you for shopping with us!


We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.


Item NO.:BV B03560

Hardware

Draw	QTY	NO.	
® ∰ Screws Ø4x14mm	80	Н	
€∜ Two-in-one connector	24		
∰) Two-in-one connector	24		<
Wood plug	5		
وريون Plastic anchor(Ø10mm)	8	J	
O Screws for fix on the wall	8	K	
G Bracket (53x70x44mm)	4	L	
		М	
	Screws Ø4x14mm Two-in-one connector Two-in-one connector Wood plug Plastic anchor(Ø10mm) Screws for fix on the wall	Screws Ø4x14mm 24 Two-in-one connector Two-in-one connector 5 Wood plug Plastic anchor(Ø10mm) Screws for fix on the wall	Screws Ø4x14mm 80 H 24 Two-in-one connector 24 I Two-in-one connector 5 Wood plug 8 Plastic anchor(Ø10mm) 8 Screws for fix on the wall 4 L M







CARE CLEANING AND MAINTENANCE

- 1.Dust regularly with a soft, dry cloth.
- 2. Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.
- 3.Excessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.
- 4. The sink top is resilient, but care needs to be taken to preserve its appearance.
- 5.Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.

