

## **Product Introduction**

## Seat Backrest



## Adjustable waist 18 segments:

Push the waist to the minimum angle (about 90  $^\circ$  ), flatten it back to its original state by 180  $^\circ$  , and then readjust it to the desired angle



% Surface seat package is detachable