



1. Remove the old sink strainer. Apply plumber's putty around the top of the sink drain hole. Place the strainer body in the sink opening and press down to secure it into position.
2. From beneath the sink, slip the rubber and paper washers over the strainer body. Align the ribs in the strainer body and mounting cup, then screw in the ferrule. Hand-tighten it first, then give it a quarter turn with a small screwdriver.
3. Slide the slip nut onto the flange tailpiece. Place the poly washer on top of the tailpiece and position it under the sink strainer. Tighten the slip nut with a wrench, but do not over tighten it.