
















# SPREADER USER MANUAL




COMPONENTS

A x 1	B x 1	C x 1	
			
D x 2	E x 1	F x 2	
			
G x 2	H x 6	I x 1	J x 2
			
K x 2	L x 2	M x 2	
			

Installation instructions:




5



Gx2



## USING YOUR SPREADER



### HOW TO USE THE SPREADER TROLLEY

TO OPEN- Push the Control Level forward until it stops against button.

TO CLOSE- Pull the control Lever fully back toward Operator.

Follow the instructions provided by the manufacturer of the spreading material.

NOTE: Make sure that the spreading material is evenly distributed. The spreading material must be dry.

1. Before feeding in the spreading material, set the dispensing lever to the OFF position (dispensing flap closed).
2. Fill the spreader trolley hopper.
3. To adjust the volume of spread, set the dispensing lever to the desired position.
4. In order to spread or scatter the material, drive the spreader trolley at an even speed (the higher the speed, the greater the scattering distance).
5. Close the dispensing flap as soon as you stop the spreader trolley (dispensing lever in OFF position).