
ADIRONDACK CHAIR

Assembly Instructions



Important - Please read these instructions fully before starting assembly

HASSLE-FREE WARRANTY

We stand behind the quality of our products. For full warranty policy, email: poly@homeselecting.com






A101-018-001



If you need help or have damaged or missing parts, please email: poly@homeselecting.com

Please check you have all the components listed below.

Note: The illustration of the product shows the exact position of each part. Check when assembing



Hardware & Tools


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than required.

1x4		2x14	3x2
M6x80MM Screws		M6x65MM Bolts	M6x90MM Bolts
4 x16	5 x16	6	7
0			
Washer	Nut	Wrench(Included)	Hex Key(Included)

Assembly Instructions


If you need help or have damaged or missing parts please email: poly@homeselecting.com

⚠ Caution: Please do not over-tighten bolts and screws during assembly.



STEP 1

Use 2, 4 and 5 to fix D and F as shown. Use 2, 4 and 5 to fix E and F as shown.



Assembly Instructions

STEP 3

STEP 4

Use 1 to fix A and F as shown.

3x2

⚠ Caution: Please do not over-tighten bolts and screws during assembly


Use 3, 4 and 5 to fix A and B as shown.

Use 3, 4 and 5 to fix A and C as shown.


If you need help or have damaged or missing parts, please email: poly@homeselecting.com

If you need help or have damaged or missing parts, please email: poly@homeselecting.com

⚠ Caution: Please do not over-tighten bolts and screws during assembly.



Use 2, 4 and 5 to fix H, J and G as shown.



•When not in use, cover the product with a protective cover to keep it clean and prolong its

Assembly Instructions

Check you have all the components and tools listed Do not stand or put weight on the product, this could

Warnings

on the page 2.

Remove all fittings from the plastic bags and separate them into their groups.

area, small parts may cause choking if swallowed. Make sure you have enough space to layout the

parts before starting.

Keep children and animals away from the work

Assemble on a soft level surface to avoid damaging the unit or your floor.

Important - Please read these instructions fully before starting assembly

cause damage.

Assemble the item as close to its final position (in the same area) as possible.

Do not place furniture directly in front of radiators, fires, or any other source of heat.

If you need help or have damaged or missing parts,

please email: poly@homeselecting.com



The assembly will be easier with 2 people while 1 person could also do the job.



Cleaning & Maintenance

•Clean the product with a solution of mild soap and water. Dip a soft cloth or sponge into the solution and wipe down the entire surface.

•After cleaning, thoroughly rinse the furniture with water to remove any remaining soap residue.

STEP 2

Use 2, 4 and 5 to fix B and D as shown.

Use 2, 4 and 5 to fix C and E as shown.

Use rope and velcro to combine the cushion and the chair together