



INSTALLATION GUIDE




Packing Lists


Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact us to obtain any missing parts.




1 Right Side Panel *1




2 Left Side Panel *1




3 Upside Hanging Rail *1




4 Underside Hanging Rail *1




5 Fixed Shelf *1




6 Back Panel *3




7 Adjustable Shelf *1




8 Top & Bottom Panel *2



9 Door Panel *2




10 Wall Cleat *1



Accessories



a Two in one screw * 20



f Door hinge * 4



b Eccentric gear * 20




g Handle * 2



d Tapping screw * 24



h Expansion screw * 2






e Wooden pole * 4




j Panel support * 4





Tools Required



Adjust connecting piece direction until it is properly lined up with the hole.








Insert bolt when connecting piece direction is properly lined up.



Installation Instructions

1 Install the Two in one screw, Wooden pole and Eccentric gear on Workpiece

①、②、⑧




Installation Instructions

2

Connect ③ to ①, ④ to ①.

Note the beveled edges are down.



b





x2

e




x2



Installation Instructions

3


Connect ⑤ to ①.



b




x2




Installation Instructions

4


Install ② to the combination of ③④⑤.



b		x4
e		x2





Flip 90°



Installation Instructions

5

Install with the bottom panel ⑧.



b




x6

Installation Instructions

6

Insert 3 back panel ⑥.



Installation Instructions



7

Install the top panel ⑧ with them.

b





x6



8

Fix the door hinges onto the doors ⑨.



d



x8

b




x4

Installation Instructions

9

Installation of cabinet doors and handles.



d  x16



g  x2



Tapping screw (lock the oval hole screws inside first to adjust the upper gap, after positioning, then lock the two screws at the front) Serew the screws on the hinge to get the doors perfectly fit.



【 Sketch Map For Adjusting Cabinet Door In Three Dimensions 】

Inside / Outside





Front and rear adjustment in three dimensions. The clearance between door board and cabinet side board can be changed only by adjusting screw "A"

Left / Right



Adjustable screw "B"
Left and right adjustment in three dimensions

Up / Down






Vertical adjustment in three dimensions
Verticality and clearance between top and bottom can be corrected by adjusting screw "C" on hinge base board.

Installation Instructions

10

Install the Panel supports **j** on the cabinet, and put shelf **7** onto the Panel supports.



j




x4

Installation Instructions

11

Determine the desired mounting location, Fix the Wall Cleat on the wall and install the cabinet.

Note: Pay attention to the direction of the hanging panel (beveled edge upwards).



Care and Maintenance

- Cleaning with a dry cloth may be sufficient.
- For other stains or marks, wipe gently with a damp cloth.
- Do not use strong detergents or abrasive cleaners; they may damage the surface of the cabinet.
- As the product is sealed during transportation, please open the cabinet for several days after receiving the goods to ventilate the smell.