
ASSEMBLY INSTRUCCIONES

ITEM NOTE: WF309739


DINING CHAIR

If you have any questions, please feel free to contact us. Email: lowes.team@qualfurn.net



IMPORTANT NOTE:

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OP CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- 2 BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- 3 DO NOT TIGHEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY STEP-UP



Part List For One			Hardware List For One		
No	Parts Desc.	Q'ty	No	Hardware Desc.	Q'ty
A	BACK FRAME	1pcs	1	Bolts 1/4"x 35mm	2pcs
			2	Bolts 1/4"x 75mm	4pcs
В	SEAT FRAME	1pcs	3	Spring Washer 1/4"x 13mm x 1.5mm	10pcs
			4	Flat Washer 1/4"x 16mm x 1.5mm	10pcs
С	RIGHT STRETCHER	1pcs	5	Bolts 1/4"x 55mm	4pcs
D	LEFT STRETCHER	1pcs	6	Screws 4 x 38mm	6pcs
Е	FRONT STRETCHER	1pcs	7	Allen Key 4mm x 60mm	1pcs
F	FRONT LEGS (LEFT)	1pcs			
G	FRONT LEGS (RIGHT)	1pcs			

