

JY

WARNING

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.


NOTICE & IMPORTANT SAFETY INSTRUCTIONS

- Please make sure that you have all parts indicated before you begin assembly of this item
- This item should be assembled on a soft surface to prevent scratching the finish during assembly
- To reduce the risk of fire, electrical shock or injury to persons or property, please follow this guide for safe use and installation

*This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to disregard this safety feature.

JONATHANY.COM

JONATHAN Y



MUSHROOM LAMP

USA1004


INSTRUCTIONS

1**Illuminate the LED.**


Get ready to brighten up your space! First, install the LED bulb into the socket by gently twisting it until it's snug. Make sure not to over-tighten it or you might break the bulb.

WARNING**FOR USE WITH LED BULBS ONLY!**


Incandescent bulbs may cause melting, bodily injury, fire or death. Keep out of reach from children.

**2****Shade the Light.**

Now that your LED is securely in place, it's time to add the shade. Simply slide it over the base and let it rest comfortably around the bulb. Make sure the tabs on the shade align with the slots on the base. Don't worry if it's a little crooked at first - we'll fix that in the next step.

**3****Rotate and Lock.**


This is where the magic happens! Rotate the shade clockwise until you feel it snap into place. That means it's securely locked and won't wobble or fall off. If it's not straight, you can adjust it until it's just right.


**4****Brighten Your World!**

Congratulations, you're done! You've successfully installed your light bulb into your new lamp. Flip the switch and bask in the glow of your newly illuminated space!

NOTE:

When it comes time to replace your bulb, use a dimmable E26 LED 4W bulb.





WARNING

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE & IMPORTANT SAFETY INSTRUCTIONS

- Please make sure that you have all parts indicated before you begin assembly of this item
 - This item should be assembled on a soft surface to prevent scratching the finish during assembly
 - To reduce the risk of fire, electrical shock or injury to persons or property, please follow this guide for safe use and installation
-

*This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to disregard this safety feature.

