



Bosch Climate 5000 Series Four Way Cassette Indoor Unit

BMS500-AAU009-1AHCXD | BMS500-AAU012-1AHCXD | BMS500-AAU018-1AHCXD



Bosch Climate 5000 Series Four Way Cassette Indoor Unit

BMS500-AAU024-1AHCXD | BMS500-AAU036-1AHCXD | BMS500-AAU048-1AHCXD



Pos.	Description	Qty	BMS500-AAU024-1AHCXD	BMS500-AAU036-1AHCXD	BMS500-AAU048-1AHCXD	Recommended Stock	Remarks
1	Ventilation ring	1.0	8-733-956-774	8-733-956-774	8-733-956-753	✓	
2	Water collector subassembly	1.0	8-733-956-754	8-733-956-754	8-733-956-754		
3	Water Level Switch	1.0	8-733-969-090	8-733-969-090	8-733-969-090		
4	Centrifugal Fan	1.0	8-733-956-780	8-733-969-091	8-733-969-092		
5	Evaporator Assembly	1.0	8-733-956-781	8-733-969-094	8-733-969-093		
6	Evaporator outlet pipe subassembly	1.0	8-733-956-782	8-733-969-095	8-733-969-096		
7	Pipe Nut	1.0	8-733-969-097	8-733-969-098	8-733-969-098		
8	Evaporator inlet pipe subassembly	1.0	8-733-956-783	8-733-956-778	8-733-956-758		
9	Pin Valve	1.0	8-733-969-099	8-733-969-099	8-733-969-099		
10	Evaporator Fixing Board subassembly	1.0	8-733-956-786	8-733-956-759	8-733-956-759		
11	Brushless DC Motor	1.0	8-733-956-784	8-733-956-760	8-733-956-760		
12	Chassis assembly	1.0	8-733-956-785	8-733-956-779	8-733-956-761		
13	Evaporator fixing hanger	2.0	8-733-953-556	8-733-953-588	8-733-953-647		
14	Pipe fixing board subassembly	1.0	8-733-956-762	8-733-956-762	8-733-956-762		
15	Gas Sensor	1.0	8-733-969-103	8-733-969-103	8-733-969-103		
16	Electronic control box subassembly	1.0	8-733-969-106	8-733-969-104	8-733-969-105		
17	Insulation plate	1.0	8-733-956-765	8-733-956-765	8-733-956-765		
18	Main control board subassembly	1.0	8-733-969-109	8-733-969-107	8-733-969-108		
19	Wire joint	1.0	8-733-969-110	8-733-969-112	8-733-969-112		
20	Room temperature sensor	1.0	8-733-969-111	8-733-969-111	8-733-969-111		
21	Reactor	1.0	8-733-956-790	8-733-956-767	8-733-956-767		
22	Humidity sensor subassembly	1.0	8-733-956-768	8-733-956-768	8-733-956-768		
23	Electronic Control Box Cover	1.0	8-733-956-769	8-733-956-769	8-733-956-769		
24	Remote controller	1.0	8-733-969-065	8-733-969-065	8-733-969-065		
25	Pipe Temperature Sensor	1.0	8-733-956-770	8-733-956-770	8-733-956-770		
26	External water pump box assembly	1.0	8-733-969-113	8-733-969-113	8-733-969-113		
27	Induction pump	1.0	8-733-956-772	8-733-956-772	8-733-956-772		
28	Accessory Kit	1.0	8-733-969-114	8-733-969-114	8-733-969-114		
29	Flare Nut	1.0	8-733-969-115	8-733-969-115	8-733-969-115		
30	Copper nut	1.0	8-733-969-116	8-733-969-116	8-733-969-116		
31	Cover Panel	1.0	8-733-962-703	8-733-962-703	8-733-962-703		

BMS500-AAU024-1AHCXD | BMS500-AAU036-1AHCXD | BMS500-AAU048-1AHCXD

Parts Pricing & Availability

For current spare parts pricing & availability information, please visit arc.bosch-homecomfort.us or scan the code below.

