


ASSEMBLY INSTRUCTION

ITEM : N715P180448

DINING TABLE



ASSEMBLY INSTRUCTION

ITEM : N715P180448

Important Note !

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.









ASSEMBLY INSTRUCTION

ITEM : N715P180448



ASSEMBLY INSTRUCTION


ITEM : N715P180448

Part List For One	Hardware List For One
Ⓐ 	①  M4*32mm
TABLE TOP (1PC)	WOOD SCREW (12PCS)
Ⓑ 	②  M6*60mm
LEG (2PCS)	BOLT (8PCS)
Ⓒ 	③ 
SUPPORT (2PC)	SPRING WASHER (8PCS)
	④ 
	ALLEN KEY (1PC)
	⑤ 
	WOOD DOWEL (4PCS)


ASSEMBLY INSTRUCTION

ITEM : N715P180448

STEP 1



WARNING: Please install the parts with care and on a clean surface.





NOTE : Do not fully tighten the bolt

BOLT M6*60mm	SPRING WAHER	ALLEN KEY	WOOD DOWEL
② x 8	③ x 8	④ x 1	⑤ x 4

STEP 2

WARNING: Place the Table Top panel on a clean and smooth surface to avoid scratches!

- * There are no pre-drilled holes on the table , please align the legs with the marking line provided and screw directly with screwdriver or electric drill.




NOTE: Fully tighten all bolts with Allen Key (4) to secure all legs.

WOOD SCREW M4*32mm
① x 12

ASSEMBLY INSTRUCTION

ITEM : N715P180448


COMPLETE



ASSEMBLY INSTRUCTION

ITEM : N715P180449

DINING CHAIR



ASSEMBLY INSTRUCTION

ITEM : N715P180449

Important Note !

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the chair legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.











ASSEMBLY INSTRUCTION

ITEM : N715P180449



ASSEMBLY INSTRUCTION


ITEM : N715P180449

Part List For One	Hardware List For One
A 	1  M4*32mm WOOD SCREW (4PCS)
BACK REST (1PC)	2  M6*50mm BOLT (8PCS)
B 	3  SPRING WASHER (8PCS)
SIDE PANEL (2PCS)	4  ALLEN KEY (1PC)
C 	5  L BRACKET (2PCS)
FRONT LEG (1PC)	6  M4*12mm WOOD SCREW (4PCS)
D 	
CUSHION SEAT (1PC)	


ASSEMBLY INSTRUCTION

ITEM : N715P180449

STEP 3



STEP 4



ASSEMBLY INSTRUCTION

ITEM : N715P180449

COMPLETE

