


ASSEMBLY INSTRUCTION

COFFEE TABLE RIGHT CORNER CHAIR



Thank you for choosing Beefurni!

Our goal is to provide high quality outdoor furniture with
outstanding customer service at an affordable price.
Please let us know how we are doing!

Problems?

Please kindly contact us 24/7 via email support@beefurni.com
As a valued customer, your satisfaction is our #1 priority!

Other products?

Please kindly find our more products at website www.beefurni.com

PART LIST

B1x1




Table Top Frame

B2x2




Table Leg Frame

B3x2






Table Side Frame

C1x1




Right Chair Arm Frame

C2x1




Right Chair Back Frame

C3x1




Right Chair Seat Frame

C4x1



Right Chair Front Frame


C5x1



Side Frame


PART LIST

A1x1




Glass Table Top

A2x1




Seat Cushion

A3x1



Long Back Cushion

A4x1




Short Back Cushion

Lx3



Foot L Shape

Ix5



Foot I Shape

Nx38



Bolt M6x30

Ox22



Washer 15x6x1

Px1




Allen Key

COFFEE TABLE


Step 1

Connect B1 with B2 by bolt N, washer O and allen key P




Step 2

Connect parts from step 1 with B3 by bolt N, washer O and allen key P




Step 3

Connect parts from step 2 with 4 foot I shape by bolt N and allen key P



Step 4


Put glass table top on surface of table to complete!



RIGHT CORNER CHAIR


Step 1

Connect C1 with C2 by bolt N, washer O and allen key P




Step 2

Connect parts from step 1 with C3 by bolt N, washer O and allen key P



Step 3

Connect parts from step 2 with C4 and C5 by bolt N, washer O and allen key P



Step 4

Connect parts from step 3 with 3 foot L shape and 1 foot I shape by bolt N and allen key P

