


## 6 Drawer Cabinet


### Assembly Instructions















**NOTE:** This instruction manual contains **IMPORTANT** safety information.  
Please read carefully before assembling the product

For assistance, please call (805) 515-3001 or email us at [after-sales-service-desk@outlook.com](mailto:after-sales-service-desk@outlook.com).



## List of Parts




# List of Hareware

No.	Hare ware	Quantity
(A)		70
(B)	 Ø15x9MM	34
(C)	 Ø12 x9MM	36
(D)	 Ø8x30MM	4
(E)		2
(F)	 14"	24
(G)	 Ø3.0x12MM	80
(H)		12
(I)	 Ø3.5x35MM	24
(J)		12
(K)	 Ø3.5x12MM	20
(L)		2


## STEP1

(A) 	3 PCS	(B) 	3 PCS
---	-------	---	-------



## STEP2

(A)



8 PCS

(B)




8 PCS

(D)




2 PCS



## STEP3

(A)




7 PCS

(B)



7 PCS



STEP4

G




8 PCS

L



2 PCS



STEP5

F





6 PCS

G



12 PCS



## STEP6

(F)





6 PCS

(G)




12 PCS



## STEP7

(A)




4 PCS

(B)




4 PCS



## STEP8

(A)



6 PCS

(B)




6 PCS

(D)




2 PCS



## STEP9

(A)



6 PCS

(B)




6 PCS

(D)



2 PCS




STEP10

K




20 PCS



STEP11

A




30 PCS

C




30 PCS





X6


STEP12



X6

STEP13

 A		6 PCS	 C		6 PCS	 I		24 PCS
---	---	-------	---	---	-------	---	---	--------




X6



STEP14

(F)




12 PCS

(G)



36 PCS



X6

STEP15

(H)




12 PCS

(J)




12 PCS



X6

STEP16



STEP17

(E) 2 PCS

