



USE and CARE

With some simple maintenance and cleaning, you can maintain the attractive appearance of your Sun Isle furniture for years of enjoyment.

Frames, Aluminum Table Tops And Finishes

Be careful to never allow water to build up in metal frames as this could cause corrosion and freeze damage in cold climates. Wash all frames and/or aluminum table tops (and wood frames and tops with polyurethane finishes) with a solution of mild soap and water. Rinse with clean water and dry with a soft absorbent cloth towel. Metal frames can be treated with a liquid wax for maximum protection against UV rays and/or salty damp air. Wood components should be wiped with a soft cloth upon receipt to remove any residual sanding dust.

All-Weather Resin Wicker

All-weather wicker is made of either PVC, Polyvinyl Chloride or PE, Polyethylene. Clean by washing frequently with mild soap and warm water. Do not use abrasive materials or cleansers. Commercial vinyl protectors may stain the cushions.

Fabrics And Cushions

If your set includes cushions, slings, and/or an umbrella they may be cleaned by hand with a solution of soap and water with a thorough, clean water rinse. Mildew and heavy stains can be removed with a quality commercial outdoor furniture cleaner and protectant. Note: Never dry clean or machine wash cushions, slings or umbrella covers as this will result in shrinkage or damage. Do not steam or use water at temperatures above 100°F when washing.

After cleaning cushions, stand on an end and allow to drip dry. Never use a commercial or home dryer to tumble dry fabric goods.

Maintain your cushions and slings by storing them in a dry area out of the elements or cover them with commercially available furniture covers when not in use. If your furniture is being used in an area where birds and trees are plentiful, covering the cushions is especially recommended.

For additional care and cleaning instructions, please give us a call at (855) 899-2111.

Do not use bleach or solvents to clean any product! This will void the warranty.

All warranty claims require proof of purchase.

CUSTOMER SERVICE

(855) 899-2111

Monday - Friday 8:00 a.m. - 5:00 p.m. EST

support@sunislefurniture.com